



**SDS/VCO Generic
Release Notes Addendum
V4.2 FSR00 PUN 26**

63103950142-0BR

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated in a commercial environment. This equipment generated, used, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manuals, may cause interference in which case the user will be required to correct the interference at his/her own expense.

NOTICE: Customers connecting this device to the network shall, upon request of the telephone company, inform the telephone company of the particular lines such connections are made, the FCC registration number, and ringer equivalence number of this device. This information is contained on the label located on the rear panel of the system.

If this device causes harm to the network, the telephone company may discontinue your service temporarily. If possible, they will notify you in advance. But if advance notice isn't practical, you will be notified as soon as possible. You will be advised of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper operation of your equipment. If they do, you will be notified in advance to give you the opportunity to maintain uninterrupted service.

If you experience trouble with the system, please contact Summa Four, Inc., 25 Sundial Avenue, Manchester, NH 03103-7251, (800) 978-6624 for repair information. The telephone company may ask you to disconnect this equipment from the network until the problem has been corrected, or you are sure that the equipment is not malfunctioning.

This equipment may not be used on coin service provided by the telephone company. Connection to party lines is subject to state tariffs.

Copyright © 1998 by Summa Four, Inc.

P/N 63103950142-0BR

Revised: 7.24.98

Summa Four, Inc. reserves the right to change specifications without prior notice.

For further information about this product, contact:

Summa Four Inc.
25 Sundial Avenue
Manchester, NH 03103-7251
(800) 978-6624

Printed In U.S.A.



This symbol on the product's nameplate means it has been tested by Electronic Testing Labs, Inc.

Table of Contents

PREFACE	1
Release Documentation Now in Two Formats	1
Definition of Terms	1
What is Included in the Release Notes Addendum?	1
What is Not Included in the Release Notes Addendum?	2
This Release Notes Addendum	2
SECTION 1 – CONTENTS OF THE RELEASE	
1.1 INTRODUCTION	1-1
1.2 HOLD TONE ADDED TO NORTH AMERICAN TONE PLAN	1-2
1.3 MFCR2 ENHANCEMENT FOR OUTPUTSING DIFFERENT CATEGORIES	1-2
1.4 NETWORK SIDE SUPPORT FOR NET5	1-3
1.4.1 Summary of Features	1-3
1.4.2 The T309 Timer	1-4
1.4.3 RESTART if the Timer T308 Expires Twice	1-4
1.5 K1197 LAYER 3 TESTING	1-4
1.6 BUSY (REORDER) TONE FOR JAPANESE NETWORKS	1-4
1.6.1 User Interface—Convert Reorder Tone To Busy	1-5
1.7 NEW MESSAGES	1-5
1.8 PROBLEMS CORRECTED IN V4.2 SINCE THE FSR00 RELEASE	1-6
1.8.1 Problems Corrected in V4.2 FSR00 PUN22	1-6
1.8.2 Problems Corrected in V4.2 FSR00 PUN23	1-8
1.8.3 Problems Corrected in V4.2 FSR00 PUN24	1-13
1.8.4 Problems Corrected in V4.2 FSR00 PUN25	1-17
1.8.5 Problems Corrected in V4.2 FSR00 PUN26	1-18
SECTION 2 – SYSTEM REQUIREMENTS	
2.1 INTRODUCTION	2-1
2.2 DATABASE CONFIGURATION	2-1
2.3 HARDWARE REQUIREMENTS	2-1
2.4 FIRMWARE REQUIREMENTS	2-2
2.5 SOFTWARE REQUIREMENTS	2-8
SECTION 3 – UPGRADING TO V4.2 FSR00 PUN 26	
3.1 INTRODUCTION	3-1
3.2 PREPARING FOR THE SOFTWARE UPGRADE	3-2
3.2.1 Additional Required Documents	3-3
3.2.2 Determining File Sizes	3-4
3.2.3 V4.2 FSR00 PUN26 Upgrade Kit Inventory	3-5

Table of Contents

3.2.4 Updating Hardware and Firmware	3-6
3.2.5 Other Necessary Items You Will Need for an Installation	3-10
3.2.6 Special System Considerations	3-11
3.3 LIVE UPGRADE PROCEDURE	3-11
3.3.1 Preparing for Live Upgrade	3-12
3.3.2 Overview of the Procedure	3-14
3.3.3 Access to Other Menus and Screens	3-15
3.3.4 Overview of the Steps	3-16
3.3.5 Performing a Live Upgrade	3-17
3.3.5.1 Step 1: Prepare for the Installation of the New Release	3-17
3.3.5.2 Step 2: Back Up the Existing Database	3-18
3.3.5.3 Step 3: Install the New Software	3-18
3.3.5.4 Step 4: Prepare to Upgrade the First Side	3-21
3.3.5.5 Step 5: Enable/Disable/Configure Optional Software	3-22
3.3.5.6 Step 6: Update the Generic	3-23
3.3.5.7 Step 7: Switch the Active Side to Standby	3-25
3.3.5.8 Step 8: Prepare to Upgrade the Remaining Side	3-25
3.3.5.9 Step 9: Enable/Disable/Configure Optional Software	3-26
3.3.5.10 Step 10: Update the Generic	3-27
3.3.5.11 Step 11: Cutover of Port and Service Cards	3-28
3.3.5.12 Step 9: Backing Up the New Database	3-31
3.3.5.13 Step 10: Clean-up	3-32
3.4 MANUAL UPDATE PROCEDURE	3-32
3.4.1 Backing up the Database and System Power Down	3-33
3.4.2 Upgrading from Generic V3.3	3-35
3.4.2.1 VCO-80	3-35
3.4.2.2 SDS-1000	3-35
3.4.2.3 SDS-500	3-35
3.4.3 Upgrading from Generic V4.0, V4.1, or V4.2 FSR00 through V4.2 FSR00 PUN25	3-36
3.4.3.1 VCO-20	3-36
3.4.3.2 VCO-80	3-36
3.4.3.3 SDS-1000	3-36
3.4.3.4 SDS-500	3-36
3.4.4 Installing the Software	3-36
3.4.4.1 Installing the Generic Software	3-37
3.4.4.2 Installing Ethernet for Host and SNMP Communication and Configuring NFS	3-39
3.4.4.3 Installing Optional Software	3-42
3.4.5 Performing a Data Base Conversion	3-43
3.4.6 Installing the Software on the B-Side	3-43
3.4.7 Verifying File Synchronization	3-44
3.5 UPGRADING TO THE 16MB/33MHZ CPU	3-44
3.6 INSTALLING THE MIB SOFTWARE	3-44

Table of Contents

SECTION 4 – KNOWN DESIGN CONSTRAINTS

4.1 INTRODUCTION	4-1
------------------	-----

SECTION 5 – KNOWN FUNCTIONAL CONSTRAINTS

5.1 INTRODUCTION	5-1
5.2 SYSTEM ADMINISTRATION	5-2
5.2.1 U508295234/TR5234: Adding Cards to End of Configured Data Base	5-2
5.3 DISK OPERATIONS	5-2
5.3.1 U805280001: System Crashes when Reading a Floppy	5-2
5.4 NETWORK BUS CONTROLLER-3 (NBC-3)	5-2
5.4.1 U803230005: NBC-3 Crashes when MSC Reboots	5-2
5.5 FOUR SPAN CARDS	5-3
5.5.1 U507185123: Processing WINK Command	5-3
5.5.2 U710290005: MVDC T1 Fails to Clear Alarms	5-3
5.5.3 U710300008: Aborted Download Does Not Resume After Switchover	5-3
5.5.4 U710310001: Display Card Data Screen Not Recording Slips	5-3
5.6 MISCELLANEOUS CARD ISSUES	5-3
5.6.1 U609230005: Outgoing T1 Stuck in CP_OUTPUL	5-3

APPENDIX A – Replacing PROMs and PLDs

A.1 INTRODUCTION	A-5
A.2 REMOVING AND REPLACING THROUGH-HOLE PROMs and PLDs	A-5
A.2.1 Removing Through-Hole PROMs and PLDs	A-5
A.2.2 Replacing Through-Hole PROMs and PLDs	A-6
A.3 REMOVING AND REPLACING SURFACE-MOUNT PROMs and PLDs	A-7
A.3.1 Removing Surface-Mount PROMs and PLDs	A-7
A.3.2 Replacing Surface-Mount PROMs and PLDs	A-8

APPENDIX B – Live Upgrade Messages

B.1 INTRODUCTION	B-1
B.1.1 Prepare for Install Messages	B-1
B.1.2 Installing New Software Messages	B-1
B.1.3 Prepare for Upgrade Messages	B-2
B.1.4 Enable/Disable/Configure Optional Software Messages	B-3
B.1.5 Card Cut-Over Messages	B-3
B.1.6 General Live Upgrade Messages	B-4

List of Figures

Figure 1.1: System Features Screen with Normal/Reorder Tone Selection	1-5
Figure 3.1: Live Upgrade on the Maintenance Menu	3-14
Figure 3.2: Live Upgrade Control Menu	3-15
Figure 3.3: Directory Structure	3-17
Figure 3.4: VCO Installation Screen	3-19
Figure 3.5: VCO Floppy Installation Screen	3-20
Figure 3.6: Install from Floppy Screen	3-21
Figure 3.7: Enable/Disable/Configure Optional Software	3-23
Figure 3.8: Enable/Disable/Configure Optional Software	3-26
Figure 3.9: Card Cut-Over	3-29
Figure 3.10: Maintenance Menu	3-33
Figure 3.11: Disk Utilities Menu	3-34
Figure 3.12: Installation Utilities Menu	3-37
Figure 3.13: Ethernet Installation Utilities Menu	3-39
Figure 3.14: Ethernet Configuration Menu	3-40
Figure 3.15: Optional Software Installation Utilities Menu	3-42

List of Tables

Table 2.1: Common Firmware Requirements	2-3
Table 2.2: ISDN Optional Products Firmware Requirements	2-7
Table 2.3: North American Feature Package Firmware Requirements1	2-8
Table 2.4: V4.2 FSR00 PUN 26 Software Requirements	2-9
Table 2.5: V4.2 FSR00 PUN 26 Optional Products Software Requirements	2-10
Table 3.1: File Sizes	3-4
Table 3.2: Upgrading Hardware & Firmware (Cards in Your System Before Upgrade)	3-6
Table 3.3: Installing New Cards (if Included in the Upgrade Kit)	3-9

PREFACE

Note: These release notes for V4.2 FSR00 PUN 26 are provided in a different form than previous releases of this product. Please note the following changes.

Release Documentation Now in Two Formats

In an effort to make the documentation easier to use and to highlight change, Summa Four has elected to provide release documentation in two formats. A baseline will be established with each FSR release (FSR00, FSR01, etc.). For these baseline FSR releases, complete release note documentation will be provided in the format that has been traditionally used. For PUN releases, a shortened version of the release notes (a release notes addendum) will be provided that deals only with the incremental changes since the product's documentation baseline. More detail on content is contained below.

Definition of Terms

FSR Release

The initial (and subsequent) release of the Generic containing significant number of fixes and/or minor functionality change.

PUN Release

An intermediate release of the Generic containing fixes and/or a small number of minor functionality changes.

FSR Release Notes

Documentation provided with each FSR release that completely describes the Generic, including complete lists of design and functional constraints.

Release Notes Addendum

Documentation provided with a PUN release that describes the incremental changes since the previous FSR or PUN release. The complete product description is a combination of the FSR release notes and PUN release notes (the Release Notes Addendum).

What is Included in the Release Notes Addendum?

This document contains the following:

- A cumulative list of new features since the FSR release
- A cumulative list of fixes since the FSR release
- A cumulative list of Known Design Constraints since the FSR release
- A cumulative list of Known Functional Constraints since the FSR release
- Installation Instructions for the current PUN release (essentially unchanged from the FSR release)
- Specific firmware and software download changes since the previous FSR (or PUN) release

What is Not Included in the Release Notes Addendum?

Since complete documentation is provided with the FSR release, the following is not included in the PUN release notes (the Release Notes Addendum):

- Functionality introduced with the FSR release
- A complete list of Known Design Constraints (See Section 4 in the V4.2 FSR00 release notes and, for additions, the V4.2 FSR00 PUN26 release notes addendum.)
- A complete list of Known Functional Constraints (See Section 5 in the V4.2 FSR00 release notes and, for additions, the V4.2 FSR00 PUN26 release notes addendum.)
- Database Card Configuration information for new systems (See Appendix A in the V4.2 FSR00 release notes.)
- Re-installation instructions for the Generic—the conventional procedure, not Live Upgrade (See Appendix B in the V4.2 FSR00 release notes.)
- MIB configuration information (see Appendix C in the V4.2 FSR00 release notes)

This Release Notes Addendum

For this release, complete information is contained in the V4.2 FSR00 Release Notes, Part Number 61220300042, which was shipped with the FSR00 release and which is shipped with all subsequent PUN releases. The FSR00 release notes are also available on the Summa Four WEB site, <http://www.summa4.com/support/library.htm>.

Section 1

CONTENTS OF THE RELEASE

1.1 INTRODUCTION

Generic V4.2 is the system software for all SDS and VCO Series systems. V4.2 FSR00 PUN 26 is an incremental release that consists of the following components:

- Five (5) Generic V4.2 FSR00 PUN 26 software diskettes that contain the Generic V4.2 PUN 26 files. These files include the database files and the card download files.
- Optional diskettes. For example: TeleRouter, Ethernet (includes the MIB Supplemental disk), ISDN, NFAS, and NI-2.

Refer to Appendix B in the V4.2 FSR00 Release Notes for information on installing the Generic software, or *Section 3* for information on upgrading your system to V4.2 FSR00 PUN 26.

If any of the required diskettes or technical publications are not in this package, contact Summa Four, Inc. Technical Support at 1-800-9SUMMA4 (or 603-695-1293).

NOTE: This PUN 26 release documentation is an accumulation of changes to the Generic V4.2 FSR00 since its release and includes PUN 22, 23, 24, 25 and 26 changes.

New systems shipped with V4.2 software have all generic and download files installed on the system hard disk. If you need to re-install the software, you must install all files from the five V4.2 diskettes onto the hard drive as outlined in Appendix B of the V4.2 FSR00 Release Notes. If you are upgrading to V4.2 FSR00 PUN 26, you must install all files from the five V4.2 diskettes onto the hard drive as part of the overall upgrade steps outlined in *Section 3*.

Generic V4.2 FSR00 PUN 26 provides full upgrade compatibility with previous versions of Generic software.

The Generic V4.2 FSR00 PUN 26 release includes:

- Fixes since PUN 25 — refer to *Section 1.8.5*
- Added tone for North American customers (DTG firmware V1.25) — refer to *Section 1.2*

The Generic V4.2 FSR00 PUN 25 release included:

- Fixes since PUN 24 — refer to *Section 1.8.4*

The Generic V4.2 FSR00 PUN 24 release included:

- MFCR2 Enhancement for Outpulsing Different Categories — refer to *Section 1.3*
- Fixes since PUN 23 — refer to *Section 1.8.3*
- Support for the new 16Mb, 33MHz CPU

The Generic V4.2 FSR00 PUN 23 release included:

- NET5 Network Side Support — refer to *Section 1.4*
- A new Feature Flag for Busy Tone in Japanese Networks — refer to *Section 1.6*
- Fixes since the V4.2 FSR00 release — refer to *Section 1.8.1* and *Section 1.8.2*
- New Messages — refer to *Section 1.7*

The Generic 4.2 FSR00 release included (refer to V4.2 FSR00 Release Notes, 61220300042, available on the Summa Four WEB site www.summa4.com/support/library.htm, for details):

- National ISDN-2 (NI-2) Option
- Drop and Insert Card Support
- ISDN NET5 Overlap Sending
- Network-side Japanese ISDN
- Call throughput performance enhancement
- Live Upgrade
- Remote File Transfer
- Inverted E&M
- Host Failure Detection
- Configurable IP Subnet Mask
- Core Dump

1.2 HOLD TONE ADDED TO NORTH AMERICAN TONE PLAN

The North American Tone Plan has been enhanced by adding a Hold Tone at timeslot 4DA. The Hold Tone uses the 480 Hz tone at -17dB. (High Tone) with a timing of 0.25 sec. on, 2,75 sec. off, repeated. No other tones have been changed. See Table 2.3 in *Section 2* for checksum and version information and an important note.

1.3 MFCR2 ENHANCEMENT FOR OUTPUTTING DIFFERENT CATEGORIES

In order to output a category digit, a user has to define an output rule with the token OPCAT. The OPCAT token takes a single digit field as a parameter where the category digit can be specified. If a user wants to output "n" different category digits at different times, "n" different output rules are required, where each rule would specify a different digit. Since there are a limited number of output rules, this could be a resource limitation.

Two new tokens have been added to address this problem. These are the OPCAT2 and IPCAT2 tokens. See also fix U802090003 in *Section 1.8*.

The user is now able to specify the new OPCAT2 token in the output rule table and the new IPCAT2 token in the input rule table via the screen manager or via SNMP.

Both of these new tokens are fieldless tokens. That is, there is no parameter field associated with them.

The call record structure currently supports five fields whose values can be supplied by a \$69 host command at run time. These fields are:

- ANI field
- Field 1
- Field 2
- Field 3
- Field 4

The call record is expanded to include a sixth field which is called Field 6 (not Field 5 because code uses 0, 4, and 5 to refer to the ANI field). Field 6 in the call record is capable of holding a single digit (the category digit).

The \$69 host command is used to populate Field 6 with a category digit at run time. Now all a user need do is specify an outpulse rule with the OPCAT2 token. Any time the OPCAT2 token is encountered in a rule, the Generic extracts the category digit from the call record if Field 6 has been populated (the call record maintains information as to the presence of data in a field) and also the size of the data (number of digits).

A single rule can then be used to specify any category digit (as opposed to a single rule per-digit). The user sends a \$69 host command at run time that specifies the category digit using Field 6 in the digit outpulse control segment of the command where the command specifies an outpulse rule that contains the OPCAT2 token.

The IPCAT2 token is provided so the category digit can be collected from an inpulse stream. When processing an inpulse rule, if the IPCAT2 token is encountered, a single digit is collected and stored as a Field 6 digit in the call record.

1.4 NETWORK SIDE SUPPORT FOR NET5

Network side NET5 ISDN Primary Rate Interface is a variant of CCITT and is a separate feature from User side NET5. The NET5 Network side feature provides the functionality of the User side feature plus the Network side capabilities.

Network side NET5 ISDN requires the E1-PRI 120 Ω (NET5) card Rev A0CR (or later).

1.4.1 Summary of Features

Functionality common to both Network and User side NET5:

- All features of the User side are supported
- The message set
- The information element set Network Side functionality

- Modified User Side call states, timers, and event processing to support the Network Side
- Outgoing RESTART after expiry of timer T308
- Mandatory network timers
- Implementation of timer T309

Additional support for the following (both Network and User Side):

- Advice of Charge supplemental service
- CRC4 programmability for all countries
- Sending Status inquiry

1.4.2 The T309 Timer

The T309 timer is optional for the User side, but is mandatory for the Network side. Per the ETSI specification, "In case of data link failure the network stops all timers relative to the call, releases the call inside and starts timer T309. It then sends a DISCONNECT message with cause 41 'Temporary failure' and clears at the other party's interface. If the low layer recovers normally before timer T309 times out, the network sends a DISCONNECT message and clears at that interface."

1.4.3 RESTART if the Timer T308 Expires Twice

When a RELEASE is sent as a response to a DISCONNECT message, the layer3 starts the timer T308. If a RELEASE message is not received within time T308, a RELEASE message is sent for the second time. If the other side continues to fail to respond, a RESTART message is sent to the other side and the call is cleared normally.

1.5 K1197 LAYER 3 TESTING

This system feature flag is not intended for customer use. It supports the K1197 Conformance tester and is enabled only when testing with the K1197. Valid values are Y and N. Set to Y (enabled) and the Datalink Release report from the card is ignored. Enabling this feature also causes Sync Source switching to stop. Set to N to disable conformance testing.

1.6 BUSY (REORDER) TONE FOR JAPANESE NETWORKS

A new feature flag has been added to the System Features screen to provide selection of an alternate busy tone for Japanese networks which use a normal busy tone instead of the reorder tone during PSC (Permanent Signaling Condition) processing on a port. See U711120006 in *Section 1.8.1*

1.6.1 User Interface—Convert Reorder Tone To Busy

The default setting of the new feature flag is "N" which results in the normal reorder tone during PSC. When this flag is set to a "Y" the normal busy tone is presented instead of reorder. See *Figure 1.1*.

S Y S T E M F E A T U R E S			
FEATURES	ALLOWED (Y,N)	FEATURES	ALLOWED (Y,N)
Redundant System	Y	Send All ISDN Connect Reports	N
Output Periodic Alarm Reports	N	Enable \$66 Cmd Host Checking	N
Card/Alarm Status at Init.	N	Cut Thru For Non-ISDN Alerting	N
Manual Intervention For SLIP/OOF	N	Enable 4th Column DTMF	N
Enable Grace Timing On Null Rule	N	Set MVDC-Backplane to A-Law	N
Disable Card Error Report/Reset	N	Enable AllPortsDeactivated Alm	N
Enable Digit Field Reporting	N	\$EA Reports on DChannel RESTART	N
Suppress PSC/Rule Abort Messages	N	Enable NET5 Overlap Receiving	Y
Enable Host Password Check	N	Send All ISDN Disconnect Report	N
Force Bearer/Lap Activation	N	Convert Reorder Tone To Busy	N
Enable MFC-R2 Supervised Clear	N	K1197 Layer 3 Testing	N
Enable SLIC Guarded Disconnect	N		
Enable CPA Monitor Disconnect	N		
Revert to Basic Redundancy	N		
Send Reports Before Guard Time	N		
Enable ISDN Manual Disconnect	N		

TP000131

Figure 1.1: System Features Screen with Normal/Reorder Tone Selection

1.7 NEW MESSAGES

There are two new diagnostic tests that are now run on an MVDC T1 card while it is in the diagnostic state. See U711010001 in *Section 1.8.2*. The messages are:

"DGN45: %s Test Aborted, Card Went OOS -ATP- %d Tests Executed"

"DGN46: %s Test Aborted, Card Went OOS -STF- %d Tests Executed, %d Failed"

1.8 PROBLEMS CORRECTED IN V4.2 Since the FSR00 Release

See the applicable ISDN release notes for a listing of ISDN issues that have been fixed.

1.8.1 Problems Corrected in V4.2 FSR00 PUN22

TR #	Corrected Problems
U706250004	<p>Previously, if a bad DRC-48 card or a DRC-48 that was not in the database was inserted in a slot, an "FRM341: NBC Error - Comm Bus Interf- DID err, 3 reset/polling cycles done" message was generated in the Log file. Once this message appeared, the DRC-48 card would not activate other than via the console.</p> <p>This has been fixed. A DRC-48 card inserted after the FRM341 message will now activate by itself without manual intervention.</p>
U706250005	<p>5191: There are now log messages that indicate the PCM coding configuration (A-Law or μ-Law) whenever a 4xT1 or 4xE1 card is brought into service: "FRM103: T1/E1 Card Configured for U-Law- RLS X,X,XX-span" and "FRM104: T1/E1 Card Configured for A-Law - RLS X,X,XX-span." When the configuration is changed, the message indicates the change.</p> <p>4.2 DS: While restoring the 4xT1/E1 card, the log messages for the configuration of the A Law/Mu Law were not found in the log file. These should have been generated to indicate the PCM coding law configuration used whenever the card was brought into service or when the configuration was changed for the PCM coding law.</p> <p>New behavior: When a span of 4xT1/W1 card is activated, its PCM coding law is indicated by a log message "FRM125: T1/E1 Card Configuration For U-Law - RLS X,X,XX-span" or "FRM126: T1/E1 Card Configuration For A-Law - RLS X,X,XX-span" is printed to the log file and on the console terminal.</p>
U707290001	<p>Previously, when the system attempted to write to a protected floppy disk, a misleading error was returned. The message was: "Error During Disk Operation."</p> <p>The correct message now appears: "Error: Disk Write Protected or Bad."</p>
U708070003	<p>Previously, during a switchover from Active to Standby, all ports on the new standby side in CP_SUBRAT state were forced to CP_IDLE.</p> <p>Normally ports not in CP_STAB and CP_SETUP (with Basic Redundancy) are forced to CP_IDLE. Attached resources are also released. Ports in CP_SUBRAT were treated similarly.</p> <p>Now ports in CP_SUBRAT are no longer affected, even in systems with Basic Redundancy.</p>

TR #	Corrected Problems
U708130003	<p>Previously, if a bad MFCR2 card or a MFCR2 that was not in the database was inserted in a slot, an "FRM341: NBC Error - Comm Bus Interf- DID err, 3 reset/polling cycles done" message was generated in the Log file. Once this message appeared, the MFCR2 card would not activate other than via the console.</p> <p>This has been fixed. An MFCR2 card inserted after the FRM341 message will now activate by itself without manual intervention.</p>
U708130004	<p>Previously, if a bad card or a card that was not in the database was inserted in a slot, an "FRM341: NBC Error - Comm Bus Interf- DID err, 3 reset/polling cycles done" message was generated in the Log file. Once this message appeared, any valid card (configured in the database) would not activate other than via the console.</p> <p>This has been fixed. A card inserted after the FRM341 message will now activate by itself without manual intervention.</p>
U708130006	<p>Previously, if a bad IPRC-64 card or a MFCR2 that was not in the database was inserted in a slot, an "FRM341: NBC Error - Comm Bus Interf- DID err, 3 reset/polling cycles done" message was generated in the Log file. Once this message appeared, the IPRC-64 card would not activate other than via the console.</p> <p>This has been fixed. An IPRC-64 card inserted after the FRM341 message will now activate by itself without manual intervention.</p>
U708220002	<p>Previously, if a bad NBC-3/DTG-2 card or a NBC-3/DTG-2 that was not in the database was inserted in a slot, an "FRM341: NBC Error - Comm Bus Interf- DID err, 3 reset/polling cycles done" message was generated in the Log file. Once this message appeared, the NBC-3/DTG-2 card would not activate other than via the console.</p> <p>This has been fixed. An NBC-3/DTG-2 card inserted after the FRM341 message will now activate by itself without manual intervention.</p>
U710130001	<p>There was an issue in which 4xT1 cards took an excessive amount of time to report an inward seizure. In addition, the 4xT1 port did not report the seizure within a consistent time period. The FXS ground start timer was changed to a "one-phase" counter which is tested against a configurable timer value. An FXS or FXO ground start port on the 4xT1 card will now report an inward seizure after the off-hook timing requirement has been satisfied.</p>
U710140005 U708280004	<p>Previously, the size of the DBvers.tbl failed to properly update after a database conversion. In the previous Generic release the table size was 306 bytes, which remained unchanged. (This was further complicated by the fact that the empty table size in V4.2 is 324 bytes.) In a related matter the table size remained at 288 bytes following an upgrade from a V3.3 database.</p> <p>The table size after upgrade is now 324 bytes.</p>

TR #	Corrected Problems
U710290003	<p>The MVDC-T 1 card experienced problems with set up for conference calls. No voice path was established to the DCC even after the port was properly added to the conference. The code has been changed to allow set up of the MVDC-T1 card with the \$6D command in the same manner as the 4xT1 card.</p>
U711030003	<p>A problem occurred when MVDC-T1 spans were used for primary and secondary incoming timing source. Following a primary loss the timing did not switch to secondary. Instead, the internal clock was used. This was fixed as part of a more general solution to the problem of a failure to switch to internal timing for a momentary (less than two second) loss of carrier and when no secondary timing was configured.</p> <p>MVDC-T1 cards now switch properly to secondary timing (when previously so configured).</p>
U711120004	<p>Previously, when a 4xT1/E1 span was taken out of service from the Maintenance menu, both active and standby sides of a redundant system sent a \$D9 report to the Host indicating an OOS state. When the span was restored, a \$D9 report was generated only by the active side. The Host connected to the standby side did not receive a report.</p> <p>The code has been modified to remove a check of the active/standby side status associated with the span before the \$D9 message is sent. The result is that a \$D9 message is generated both active and standby sides of a redundant switch.</p>
U711120006	<p>The VCO system was designed to present a fast busy (reorder) tone during PSC processing on a port. This fast busy tone is not supported in Japanese networks. The normal busy tone is, instead, used in Japanese networks. This has been accommodated by the addition of a feature flag on the System Features screen. This feature "Convert Reorder Tone To Busy" when set to "Y" results in the normal busy being presented to the caller instead of fast busy.</p>

1.8.2 Problems Corrected in V4.2 FSR00 PUN23

TR #	Corrected Problems
U507315154 (TR5154)	<p>Trace files did not close at the end of the calendar day unless tracing had previously been disabled. The system continued to add trace data to the previous date's trace file.</p> <p>This has been fixed.</p>
U604190004	<p>Previously, when a span was taken out of service on a 4xE1, the green LED did not illuminate. It now does so, to indicate an OOS span.</p>

TR #	Corrected Problems
U610030003	<p>Cold boots would intermittently cause an error "FRM051 Error Reading Download File-Code 0x73e Filename C:/boot/4xE1.dwn" and "... Filename C:/boot/mvdct1.dwn." The cards would then load properly. This problem occurred more frequently with a greater number of cards (such as 4xT1/E1s).</p> <p>The messages no longer occur during a cold boot.</p>
U704090001	<p>If the external timing source was connected only to the active side NBC-3, or if the external timing source was removed from the standby side, the standby side continuously reported FRM020 and FRM040 messages reporting the failure to obtain an external clock on the standby side. This was because the Generic did not inform the NBC-3 to switch to internal clock.</p> <p>Now, when the standby side NBC-3 reports an inability to sync to the external clock, the Generic instructs the NBC-3 to switch to internal clock. The NBC-3 selects internal clock and sends an acknowledgment message to the Generic.</p>
U706230001	<p>This was a problem that occurred with PRI/N call processing. The switch would intermittently report "FRM182: Outpulsing In Incorrect State - RLSP x, x, xx, x." This was caused by an error of the Generic code that failed to perform a check on the state of the port before a call.</p> <p>Now the outgoing port is released as expected and no FRM182 report is generated.</p>
U707080004	<p>The problem of new trace files not being created at midnight, even when the trace was left enabled, has been corrected.</p>

TR #	Corrected Problems
U707300004	<p>When the external timing source was lost, the system would switch to the internal timing source. However, once the external timing source was restored, the system did not switch back to external as it should have. In addition, upon external timing source loss, a major alarm was not generated.</p> <p>The corrected behavior of the system is that a major alarm is now set and cleared when the external clock is lost and then recovered. The following FRM messages are displayed and sent to the log: FRM504: Major Alarm Set For - ALM067: NBC Loss of External Sync. FRM511: Major Alarm Clear For - ALM067: NBC Loss of External Sync. These alarms also appear under the Major alarms of the System Alarms Display option.</p> <p>In addition, \$F0 reports similar to the following are sent to the host when ALM67 is set and cleared: df 44 00 00 f0 43 05 01 05 df 44 00 00 f0 43 00 00 00 The \$43 in the \$F0 report indicates this new alarm code.</p> <p>Also, upon external timing reference loss, the Generic tries three times, at one minute intervals, to reselect the external clock. If the NBC3 reports a success on the first attempt, subsequent attempts are aborted. If the incoming timing source is selected immediately after the external timing reference loss, the Generic aborts the external clock selection.</p> <p>Since the host now receives an indication of the external clock loss, it can send a \$C002 command at any time to retry selecting the external source, or switch to an incoming source.</p>
U708010008	<p>Previously, the inactivity time on remote terminals was inconsistent; the timer would vary from three to eight minutes. Now, if a user logs on to a remote terminal and then does nothing, after five minutes have elapsed the connection is closed with a logout message.</p>
U708140001	<p>There was a problem with the IPRC card still being able to run diagnostics while it was active. Users would see the proper message, "ERROR: Receiver NOT in Diagnostic Mode." However, if the user pressed the Enter key, the test would run. This problem has been corrected.</p>
U708200006	<p>Previously, when a card was deleted through the admin console on the active side, the number of timeslots on the active side was reduced by the number of timeslots occupied by the deleted card. The number of timeslots on the standby side however, was not reduced. This could cause problems if a switchover to the standby side occurred, since these timeslots remained occupied as far as the system was concerned, and therefore, would remain unused.</p>

TR #	Corrected Problems
U709020009	<p>There was a problem with the standby side NBC3: when the card was pulled out of the slot, the active side continued to display its status "S" (standby) instead of "O" (out of service). Now, the active side takes the card's state to out of service and declares an update channel failure.</p>
U709110001	<p>There was a problem with running diagnostic tests on the IPRC. Users could not stop the test by pressing a key, and the screen would lock until the tests were completed. Now, if an operator presses a key, the tests are aborted and the DGN09 or DGN11 messages are displayed.</p>
U709120005	<p>Previously, when users printed the Database Detail from the Database Administration menu, the Ethernet TCP/IP and/or Subrate Configuration detail was not included.</p>
U709180001	<p>A problem existed when a cable was pulled for fewer than two seconds from a carrier which was acting as the primary timing source. (For that brief a period of time, no alarms are generated.) The NBC3 however, would lose its synchronization to the incoming timing source. Therefore, if no secondary timing source was configured, the VCO switched to internal instead of trying to use the primary again.</p> <p>Now, if a cable is removed from the adapter of a card (span) being used as primary timing source for less than two seconds, the Generic will try to use it again, rather than switching to the internal clock and generating alarms.</p>
U709230001	<p>When a \$49 command is used to connect a controlling port and an associated port for an outgoing call, the active side removes the start and end records after redirecting the associated port (from incoming to outgoing). An issue previously existed in which the standby side's start and end records were not deallocated properly. This caused the start and end records to accumulate until they exceeded the memory pool size. In addition, the number of allocated start and end records were not in synch between the active and standby sides, and the number of start and end records would not reset to zero, even after the call had been torn down. The system could not deallocate the start and end records while the major state of the standby side's ports were in CP_SETUP.</p> <p>With this release, the \$49 command's connection operation deallocates the start and end records on both the active and standby sides, if the associated port is formerly allocated with those records. Therefore, the start and end record exhaust condition will not occur on the standby side due to this call scenario.</p>
U710140001	<p>When the card used for Incoming Primary timing was pulled, the switch went to Internal timing rather than Secondary timing.</p> <p>Secondary timing is now used when the Primary timing card is pulled.</p>

TR #	Corrected Problems
U710240003	<p>The \$72 command (seize and unseize a port) sent to the switch did not function properly. When a \$72 command was processed to seize a port, the port should have been flagged as SEIZED. Instead, it was flagged as ANSWER. Therefore, the system saw nothing to unseize and the port remained unavailable.</p> <p>The conditions of the port are now acknowledged properly.</p>
U710280002	<p>The class of service bits are set according to the characters entered. Valid characters are A, O, T, and 2, or a combination of these characters. However, the software did not reject certain invalid combinations. If a call was routed through this port the switch rebooted. This was found in Line, Trunk, and PRI Card configurations.</p> <p>The port's class of service bits are now verified. If invalid, the function's logic rejects it and an error message is printed.</p>
U710300006	<p>When the AM2-D bulk call generator was configured as FXOGS, and the MVDC T1 card configured as FXSGS, only 50% of the calls were processed. After the first call, the ports stayed in CP_GARD, GD_NORMAL mode. The next call from the load box hung up the port. The MVDC T1 card saw 100% completions and the load box only saw 50% completions.</p> <p>The MVDC T1 card now reacts faster when it gets the seizure. When the MVDC T1 is commanded to abandon a call, it now goes back to an IDLE condition in a reasonable time. The port is no longer hung in an infinite loop.</p>
U711010001	<p>The System Administration master console would hang if the MVDC T1 diagnostics were running in 'Continually Loop Through Test' mode, and the MVDC T1 was pulled out of the subrack and then reinserted. The card downloaded and resumed running, but the console did not accept key-strokes to terminate the diagnostics.</p> <p>The diagnostics tests are now only run on an MVDC T1 card which is in the diagnostic state. If the card goes to an out-of-service (OOS) state, the test loop is terminated. The operator is notified, via a console message, that the diagnostics test has been terminated due to a card going OOS.</p> <p>Two new diagnostic messages are associated with this fix: "DGN45: %s Test Aborted, Card Went OOS -ATP- %d Tests Executed" "DGN46: %s Test Aborted, Card Went OOS -STF- %d Tests Executed, %d Failed"</p>
U712010001	<p>When the \$67 command was issued to remove a DTMF receiver from a port, the command was rejected, indicating that there was no resource of this type in the call's resource chain. The m_state of the controlling port was being changed when the receiver was detached.</p> <p>Now, when the command is rejected, the port's m_state does not change. The m_state is changed only when the command is executed successfully.</p>

TR #	Corrected Problems
U712090001	<p>The CPA Monitor Disconnect feature did not function properly. After a call was established, and the calling party disconnected, the UTC port did not return to an IDLE state.</p> <p>The UTC port is now released when the calling party hangs up.</p>
U712100002	<p>A feature was recently added to improve the speed of the system. However, due to an adjustment of calls-in-queue, the messages transferred between the switch and host were not being prioritized properly. This resulted in a HOST_TX_Q overflow.</p> <p>The enhancement has been removed and the calls in queue are no longer automatically running at a higher priority in order to continue processing without getting discarded.</p>
U712160003	<p>The system failed to switch from secondary incoming timing source to primary incoming timing source. The switch selected the secondary timing source. If not there, it searched for the internal timing source, even though the primary timing source was available.</p> <p>The system now successfully switches from the primary incoming timing source to the secondary incoming timing source and vice versa.</p>

1.8.3 Problems Corrected in V4.2 FSR00 PUN24

TR #	Corrected Problems
U610160001	<p>The MVDC erroneously reported PRI D-Channel Failure as a failure. This occurred even though the switch did not have either the PRI or PRI/N option installed. The correct alarm is T1 OOF. This was caused by an error string mismatch within alarm look-up. The correct alarm is now displayed.</p>
U702280004/ U710080002	<p>During the file sync, the standby side would sometimes report database errors (RED45: Standby DB Update Error). This has been fixed.</p>
U707300004	<p>There are two problems associated with this fix. The first occurred when the external timing source was lost. When restored, the switch stayed at internal source and did not switch back to external. The second issue was the failure to generate a major alarm when the external timing was lost.</p> <p>Now major alarm is set and cleared when the external clock is lost and then restored. The following FRM messages are displayed on the screen and are sent to the logs: FRM504: Major Alarm Set For - ALM067:NBC Loss Of External Sync (SA) and FRM511: Major Alarm Clear For - ALM067:NBC Loss Of External Sync.</p>

TR #	Corrected Problems
U704140001	<p>Fixed by U708130004 implemented in V4.2 FSR00 PUN23.</p> <p>Previously, if the error message FRM341: NBC error - Comm Bus Interf-DID err was received, cards in the system could fail to come into service. This usually occurred because a card was in a slot that was not defined for that card. When this was the case, other cards, even if properly defined, could also fail to come into service because device polling is discontinued.</p>
U708260018	<p>The IPRC prompt library maintenance screen failed to show the correct data for TOTAL USAGE. When initially entering the screen it shows 0:00. Subsequent entries show correct values. Also a message "Error - No Such Prompt ID" appears if you enter a library number followed by the enter key. This is an invalid error.</p> <p>The correct library data is now shown and the erroneous error message does not appear.</p>
U709100001	<p>When multiple NFAS groups are configured in a VCO switch and the D channel of the group (other than group 1) is taken down it causes all the B channels in group 1 to be OOS-NE (Out-Of-Service Near-End). The B channels in the broken D channel remain IN_SERV.</p> <p>Now when the D channel of a NFAS group goes out of service, only the B channel ports for that group become out of service.</p>
U710290004	<p>CP_MSG_Q overflow occurs as a result of burst commands from multiple hosts connected via Ethernet.</p> <p>Command bursts from multiple hosts via Ethernet are now handled at higher volume.</p>
U711040004	<p>Slip and OOF counters were not clearing at midnight on cards such as the MVDC, 4XT1, and 4XE1.</p> <p>Counters are now cleared at midnight.</p>
U711110006	<p>If a virtual port was allocated via a \$6A command, but not connected, the port was unavailable if the host connection was lost and then re-established.</p> <p>Now if the host connection is lost and host failure action is set to call teardown, the system makes virtual ports available for allocation in the future.</p>
U712080003	<p>When an ISDN command (\$49) was issued to tear down a T1 incoming call in CP_SETUP state, the switch crashed.</p> <p>This was an invalid command. However, the switch now accepts the command without crashing the switch.</p>
U712150005	<p>This was a problem of the switch supporting loads only to 68K. This is now fixed to run at 75K.</p>

TR #	Corrected Problems
<p>U801020001 related: U207293581 (TR3581) U603040003 U709100001</p>	<p>If the span carrying the active or backup D channel of an NFAS group goes out of service, the D channel is properly identified as out of service and (if active) is switched to the backup. The B channels, however, appear to be in service and available for calls when, in fact, they are not.</p> <p>The B channels are now marked OOS-NE rather than left as IN-SERV.</p>
<p>U801130001</p>	<p>4xE1 cards running in CCS31 signaling mode were reporting MFA alarms that were inconsistent with the mode. Alarms were being generated for channel 17 for OOF, AIS (remote alarm), or all zeros for an entire Multi-frame. In CCS31 mode channel 17 is a bearer channel not a signaling channel, and the alarms are valid only for channel 17 operating in signaling mode.</p> <p>The card no longer reports MFA alarms when operating in CCS31 mode.</p>
<p>U801130009</p>	<p>This is a new feature called Party Re-Answer added to 4xE1 capabilities. This is used in Singapore to allow the called party to hang up and go offhook again, without releasing the call. The called party has to go offhook within a certain time, otherwise the call is released. The call can also be torn down by the calling party as soon as it goes onhook.</p>
<p>U802050001</p>	<p>When using a Telerouter on a VCO to provide NTT to NET5 protocol converter application, CAUSE IE for the DISCONNECT message is not propagated from one side of the cal to the other. Instead, the VCO always generates a predefined CAUSE IE of "Normal Cal Clearing" (80 90).</p>
<p>U802090003</p>	<p>This is an enhancement that allows the host application to outpulse different category digits from a \$69 command as part of the MFCR2 call processing. This provides flexibility over defining each different category digit in a different Outpulse Rule.</p>
<p>U802090005 and U802130004</p>	<p>Previously, several screens experienced a lockup problem after the EXIT_SCREEN or PREV_MENU keys were pressed. Once locked up there was no response to any key, and the screen timed out after 15 minutes. During the lockup all other Generic functions remained intact.</p> <p>There are now no screen lockups regardless of key input.</p>
<p>U802100005</p>	<p>The dbvers.tbl file in V4.2 PUN23 did not contain the latest version number for itself. When a database conversion was done, an unexpected report states that dbvers.tbl was converted Version 4 to Version 5. The number of records recorded for dbvers.tbl was also incorrect (one less than the actual number). Note that dbvers.tbl contains a value for the version number of every table in the database, including itself.</p> <p>There is no effect on the system from this error, but it could cause confusion.</p> <p>Now a database conversion will not report that any files were converted.</p>
<p>U802130004</p>	<p>See U802090005</p>

TR #	Corrected Problems
U802130005	<p>Intermittent system crashes were reported which were believed to be associated with Enhanced \$67 command processing. However, the problem could not be reproduced at either Summa Four or the customer site.</p> <p>The problem was identified from core file analysis and code inspection and a fix was implemented.</p>
U802180003	<p>When a 4xE1 card was added with its spans configured as CCS/31, time slot 17 was unavailable. It could be made available by manually P'ing it in from the maintenance menu.</p> <p>Time slot 17 is now available without manual intervention.</p>
U802230001	<p>Previously with an outbound PSTN port connected to a clear-channel port via \$6A and \$66 commands, no \$DA report was sent to the host following a switchover with the PSTN port going onhook.</p> <p>Now when a switchover is initiated and the PSTN port goes onhook, a \$DA report is sent to the host.</p>
U802240001	<p>During live upgrade while the switch is processing calls, after option F (switchover to ACT on the SBY side), the new active side (after switchover) rebooted. This has been fixed.</p>
U803020002	<p>Start/End record exhaust condition was seen during host initialization as the host sent a burst of commands to activate the ports and connect them using a \$66 command. The number of start and end records have been increased from 900 to 1600.</p>
U803110014	<p>Occasionally users experienced a problem where they could not go beyond the Main Menu, and that any attempt to use any one of the four options available on the Main Menu would then cause the user to be logged out. Once this condition occurred, both telnet and local console access would experience the same behavior. The switch did allow the user to log in, but did not allow access to any other menu beyond the Main menu.</p> <p>The forced logout and access denial no longer occur.</p>

1.8.4 Problems Corrected in V4.2 FSR00 PUN25

TR #	Corrected Problems
U802100001	<p>Prior to this fix if you attempted to exit a Telnet session with the CTRL] escape combination, the working (displayed) screen did not close and you were not returned to the login screen unless you had first logged out from the switch. Subsequent Telnet sessions would bring up the same menu from where the previous Telnet session was terminated instead of bringing up the login screen.</p> <p>The system now treats the CTRL] escape sequence as a valid logout event. The new Telnet session will always take the you to the login screen.</p>
U803110012	<p>There was a problem in the dbvers.tbl data base file that occurred with the transition from the V4.2 FSR00 PUN 23 release to the PUN 24 release. PUN 23 had failed to fill in the filename field for subrate and motomap table entries and with PUN 24 the conversion program was modified to fill in the file names. If an conversion had been performed with PUN 23, an upgrade to PUN 24 would not correct the missing table entries.</p> <p>All file names and field entries are now correctly made.</p>
U803110013	<p>Previously, when you logged out of a Telnet session and logged into the console, the console would lock up at the main menu and would not accept any keyboard input until the 15-minute system time-out. Occasionally this lockout would also occur if you exited from the Telnet session via the escape sequence resulting in keyboard input lockout after telnet reconnection.</p> <p>A logout from a Telnet session will not prevent keyboard access to the administration screen.</p>
U803190001	<p>If an IPRC64 or IPRC128 was taken out of service while their ports were engaged in active calls, a call chain corruption would occur that would subsequently cause a system dump.</p> <p>Now neither call corruption nor a system dump will occur if an IPRC64 or IPRC128 is taken out of service even if their ports are attached to calls. All calls associated with the IPRC are released when the card goes OOS.</p>
U803230008	<p>Data base conversion after an upgrade from any V4.2 FSR00 Generic release to a newer PUN release will fail if it is attempted in systems with a new 33 MHz CPU (NVRAN un-initialized).</p> <p>Prior to this fix a workaround was to upgrade the Generic before upgrading the CPU.</p> <p>With V4.2 FSR00 PUN25 both Generic and CPU upgrade can be performed at the same time. Database conversion is successful even for systems with new, un-initialized CPUs.</p>

TR #	Corrected Problems
U804010005	<p>Previously, live upgrade from V4.2 FSR00 PUN24 to V4.2 FSR00 PUN25 failed. The standby side of a redundant system would crash as soon as a live upgrade was attempted. The problem occurred only if the system was processing calls. Live upgrade could not be performed from PUN24 to PUN25.</p> <p>This problem existed only when live upgrading from PUN24 to PUN25. Customers running any other V4.2 Generic release, such as the V4.2 FSR00 base line or V4.2 FSR00 PUN23 are able to live upgrade to PUN25 successfully. Live upgrade from PUN25 onwards works correctly.</p>

1.8.5 Problems Corrected in V4.2 FSR00 PUN26

TR #	Corrected Problems
U709110003	<p>The code FRM340 would intermittently be reported for unknown reason. Normally the sequence would be similar to: FRM363: 4XT1 Internal Communications Time Out RLS x,x,x-x followed by an FRM340 code; FRM340: Code Error_api_slot_table.c, 1714:15,0,0,2 or FRM340: Code Error_api_slot_table.c, 1714:15,0,0,3.</p> <p>Code analysis has led to a code change to eliminate the FRM340 code message.</p>
U712040002	<p>Prior to this fix, the system would occasionally generate a \$09 time-out error indicating an aborted download of a 4XT1 card.</p> <p>The \$09 time-out during a 4XT1 download no longer occurs.</p>
U802170002	<p>Previously, when a \$66 command was used to connect two ports, the active side would properly show the voice path on the Port Display screen. However, the standby side would not show the voice path on the port display screen.</p> <p>Both active and standby sides now correctly show the voice path.</p>
U804080001	<p>Prior to this fix the uncompress option in the disk utilities did not work. After properly specifying a file to be uncompressed, the utility would simply ask for the file name again.</p> <p>The disk utilities uncompress option now works correctly.</p>

TR #	Corrected Problems
U804150001	<p>A cold re-boot of the switch downloads cards in a DRC, CPA, 4XT1/4XE1 sequence. Prior to this fix systems would experience errors during the 4XT1 (or 4XE1) download phase. Multiple "FRM179 Internal Port Card Errors" (parsing errors) occurred which pointed to the RLS of the CPA card.</p> <p>The CPA card was found to have been in-service during the 4XT1/4XE1 broadcast download, and the CPA card attempted to capture the 4XT1 download messages. The CPA card could not process these messages which resulted in FRM179 error messages.</p> <p>Cards are now prevented from being placed in-service until the broadcast download cycle is complete.</p>
U804290003	<p>Previously, during a switchover from primary incoming timing to secondary or internal timing, some 4XT1 or 4XE1 spans may report a momentary remote alarm condition. This alarm clears by itself after a few seconds, but the spans on which the alarm occurred are momentarily placed into maintenance state and active calls on these spans are dropped.</p> <p>Now, following a switchover from primary timing to secondary because of a carrier alarm, or a manual switchover from primary timing to internal, no remote or carrier alarms are seen on any spans and calls are not interrupted.</p>
U804290005	<p>Previously, when a span or card was used for secondary incoming timing went into maintenance state (as a result of a remote alarm), the Generic switched the timing to internal instead of primary, even if primary was available.</p> <p>Now the system switches to primary timing when a remote alarm is reported by the secondary timing source.</p>
U805120003	<p>Previously, if a switchover (initiated from via a \$C001 command or from the maintenance menu) was performed on a redundant system running a call scenario which involved returning ports from CP_STAB to CP_SETUP state, a reboot could occur on the new active side following the switchover.</p> <p>Switchover from one side to the other occurs without failure under the above conditions.</p>
U805210001	<p>Previously, the debug message "steprule -> unexpected 1" was sent to the log file during impulse rule processing in a switch configured for MF digit collection.</p> <p>This message is erroneous and has been removed.</p>

TR #	Corrected Problems
U805290004	<p>Prior to this fix, a system running call transfers under load would crash following a switchover to the standby side. A Call Chain Dump would precede the crash with a cause indication of "EXCEPTION FAULT PC=0x00000006"</p> <p>This problem occurred while the call transfer application was creating a CP_SETUP state for ports on the standby side at the time the switchover and crash occurred. This fix corrects problems associated with this scenario. Switchover occurs properly.</p>

Section 2

SYSTEM REQUIREMENTS

2.1 INTRODUCTION

This section provides a listing of system requirements for running Generic V4.2 FSR00 PUN 26. These requirements are divided into database, hardware, firmware, and software. Contact Summa Four, Inc. Technical Support at 1-800-9SUMMA4 (or 603-695-1293) for any site-specific information.

2.2 DATABASE CONFIGURATION

The VCO system is shipped to you with:

- the Generic software installed on the hard drive
- the licenses configured in the database
- the NBC-3 and DTG/DTG-2 cards configured in the database
- all cards physically installed inside the enclosure

Appendix A in the V4.2 FSR00 Release Notes contains an overview of the steps you must follow to add and configure the cards in your system.

2.3 HARDWARE REQUIREMENTS

The components listed in this section are installed in new systems prior to shipment.

To operate V4.2 FSR00 PUN26, a system must be equipped with the following components:

System Controller

- CPU Transition Module (CPU-TM) or Storage/Control I/O module
- 8 MB or 16MB RAM 68030-based CPU (central processing unit)
- SWI Version A0AR
- AAC

Storage Subsystem

- SCSI interface hard drive, 42 Megabytes or larger
- 3.5" SCSI Interface Floppy Drive

Control Circuit Cards

- NBC-3 Card Rev C0ER (or later) or E0AR (or later)
(Two NBC-3 cards are required for redundant systems; one NBC-3 for non-redundant systems.)

- BRC—Bus Repeater Card Rev B0YR (or later)—*not required for VCO/20 systems* (A BRC is required for each expansion rack—one in slot 1 in non-redundant systems, one each in slots 1 and 2 in redundant systems. SDS-1000 and VCO/80 systems only.)

Port Interface Cards (Optional)

- E1-PRI 120 Ω (NET5) Card Rev A0CR (or later)

Service Circuit Cards

- DTG/DTG-2—Digital Tone Generator
(All systems requires a minimum of one tone card to provide a quiet tone to the network.)

SNMP Management

- Ethernet Option

If you are planning to monitor and control your system remotely via SNMP, an SNMP network management application or platform is required. You will need an SNMP application to perform SNMP tests on your system. One alternative is to use the tools available with applications such as Hewlett Packard's OpenView™ or Sun Microsystem's Net Manager®. See Appendix C in the *V4.2 FSR00 Release Notes*.

2.4 FIRMWARE REQUIREMENTS

System firmware requirements common to all systems are listed in Table 2.1. Table 2.2 lists the ISDN optional products firmware requirements. Table 2.3 lists domestic (U.S.) firmware requirements. Refer to the technical descriptions in Volumes 3 and 4 of your hardware documentation set for firmware locations for each card. Instructions for removing and replacing firmware PROMS are contained in *Appendix A* of this document.

The version of the firmware on cards in your system can be obtained by going to the Card Maintenance Screen on the Main Menu. The version of the CPU firmware can be determined only examining the card. EPLDs (identified with a version number beginning with LP) also can be determined only by examining the card.

Table 2.1: Common Firmware Requirements

Card Name	Firmware	Checksum ¹	Version	Location	Changed Since V4.2 FSR00 PUN 25?	Changed Since V4.2 FSR00?
BRC	BRC	00002412	2.01	U2	N	N
CPA	See Table 2.3				N	N
CPU 8Mb ^{3,4} 25MHz	Boot Even	006E6CB3	4.04	U1	N	N
	Boot Odd	0086954F	4.04	U15	N	N
	MVME147 MVME147	5741B41F 5741B42F	2.44 ⁵ 2.44 ⁵	U30 U22	N N	- -
	MVME147 MVME147	5741B41E 5741B42E	2.43 ⁵ 2.43 ⁵	U30 U22	N N	N N
CPU 16Mb ^{3,4} 33MHz	Boot Even	006E691D	5.00	U1	N	-
	Boot Odd	00866CBF	5.00	U15	N	-
	MVME147 MVME147	5741B41F 5741B42F	2.44 2.44	U30 U22	N N	- -
DID-2	DID-2	000010C3	1.41	U2	N	N
DRC-8	DRC	00009625	5.23	U2	N	N
DRC-24/48	DRC-2	00004241	3.08	U2	N	N
Drop & Insert	D&I	00A998F6	2.01	U9	N	N
DVC	DVC	000095BE	2.07	U2	N	N
E+M	E+M	0000D381	2.06	U2	N	N
E1	E1-CAS/MERC	0000F1C6	2.13	U23	N	N
	E1-CAS/R2	00002654	2.01	U23	N	N
	E1-31B	0000EF58	3.03	U23	N	N
	E1-CAS/R2 (No CRC4)	000EDF08	3.43	U23	N	Y
	CAS PROC	00001E78	1.04	U85	N	N
	32 CHAN SETUP	0000CDDE	1.00	U113	N	N
	PCM GAIN/LAW	000011D2	1.02	U45/53	N	N
IPRC-8	IPRC 8-PORT	00220D75	1.03	U2	N	N

Table 2.1: Common Firmware Requirements(Continued)

Card Name	Firmware	Checksum ¹	Version	Location	Changed Since V4.2 FSR00 PUN 25?	Changed Since V4.2 FSR00?
IPRC-64	IPRC 64-PORT	00220DC1	1.03	U2	N	N
IPRC-128	IPRC 128-PORT	00220E0A	1.03	U2	N	N
MRC	MRC	0000EE80	3.08	U2	N	N
MVDC-T1	Local Bus	000D373B	LP100A	U35	N	N
	Com Bus	00186169	LP101A	U19	N	N
	Interrupt	000AE787	LP102	U75	N	N
	PCM Interface	001748E3	LP103A	U107	N	N
	Framer	0005FE2C	LP104	U76	N	N
	Gain/Law	0005A153	LP105B	U49	N	N
	T1 Clock	000BE051	LP106	U80	N	N
	Gain/Law	00776220	—	U50	N	N
	Boot PROM	0065B028	1.06	U10	N	N
NBC-3 Card Rev C0ER or later ⁶	LP122 SWI	00194974	LP122C	U66	N	N
	LP123 Counter	0018E096	LP123E	U13	N	N
	LP124 Chip Select	000D7B43	LP124C	U12	N	N
	LP125 Com Bus FPGA ²	—	LP125C	U43	N	N
	LP126 Com Bus EPLD	0005CED8	LP126B	U47	N	N
	LP127 Mezzanine Add.	0006C919	LP127A	U105	N	N
	Boot PROM	00F597BE	1.02	U4	N	N
NBC-3 Card Rev E0AR or later	LP141 SWI	0019204D	LP141A	U31	N	N
	LP140 Counter	00187206	LP140C	U73	N	Y
	LP139 Chip Select	000D4209	LP139A	U30	N	N
	LP125 Com Bus FPGA ²	—	LP125C	U53	N	N
	Boot PROM	00F597BE	1.02	U1	N	N

Table 2.1: Common Firmware Requirements(Continued)

Card Name	Firmware	Checksum ¹	Version	Location	Changed Since V4.2 FSR00 PUN 25?	Changed Since V4.2 FSR00?
SSC	Com Bus Control	00186169	LP101A	U24	N	N
	PCM Interface	00198315	LP130B	U76	N	Y
	Quad 9 to 1	0017878C	LP129A	U71/U70	N	N
	Redundancy Control	0017F249	LP128A	U100	N	N
	Subrate Matrix Control	000BB573	LP131	U31	N	N
	Boot PROM	00400736	1.02	U10	N	Y
SLIC-2	SLIC-2	000010B9	1.41	U2	N	N
T1	T1	00002BA5	1.26	U2	N	N
	T1 Aux Proc	00007125	1.00	U45	N	N
UTC-2 Rev A	UTC	0000F91E	6.00	U2	N	N
UTC-2 Rev B	UTC	0000ECF0	6.54	U2	N	N
4XT1/E1	4XT1/E1 68340 VIRT CM	00291041	1.08	U10	N	N
	4XT1 68302 ODD	00277AE4	1.14	U47, 93, 150, 185	N	Y
	4XT1 68302 EVEN	00242750	1.14	U48, 94, 151, 186	N	Y
	GAIN/LAW CCITT G.711	000FCD68	1.03	U25, 28, 67, 78, 120, 131, 158, 170	N	N
	PATH SETUP ROM	0000CDDE	1.00	U35, 86, 116,178	N	N
	4XE1 68302 ODD	00263E25	1.04	U47, 93, 150, 185	N	Y
	4XE1 68302 EVEN	002313DD	1.04	U48, 94, 151, 186	N	Y

Notes:

¹*The firmware label applied by Summa Four may list only the last four digits of the checksum.*

²*The checksum for the NBC-3 LP125 is not given because the programming for this item is part of the NBC-3 download file and is included in the checksum for the NBC download file.*

³*8MB RAM/25MHz CPU cards are shipped with all new systems unless 16MB RAM/33 MHz CPU cards are specially ordered.*

⁴*Since May 1998, all new systems have been shipped with V2.44 MVME147 PROMS. This firmware is supplied by Motorola.*

⁵*The 8Mb 25MHz CPU card firmware Version 2.43 and Version 2.44 can co-exist, one on one side of the switch and one on the other. However, the same version (2.43 or 2.44) must be installed on a given CPU card at locations U30 and U22. It is not necessary to replace Version 2.43 with Version 2.44 firmware.*

⁶*The Version C0ER NBC-3 card is no longer manufactured. If the card needs to be replaced, use the new, Rev E card (Version E0AR, or later) with the latest firmware and EPLDs.*

Table 2.2: ISDN Optional Products Firmware Requirements

Card Name (Software Product Name)	Optional Product Release Note Reference	Changed Since V4.2 FSR00 PUN 25?	Changed Since V4.2 FSR00?
E1-PRI (NTDASS2, DPNSS)	See the NTDASS2 Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100450142 or See the DPNSS Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100650142	N	N
E1-PRI 120 ohm (NET5) Rev A0CR or later	See the NET5 Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100550142	N	Y
E1-PRI 120 ohm (NET5) Rev A0AR or A0BR	See the NET5 Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100550142	N	Y
PRI (ISDN-PRI)	See the ISDN-PRI/ISDN-NFAS Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100950142 Note: The PRI card is not NFAS (nor NI2 nor NTTPRI) capable.	N	N
PRI/N (ISDN-PRI, ISDN-NFAS, NI2, NTTPRI)	See the ISDN-PRI/ISDN-NFAS Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63100950142 or See the NI2 Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63101150142 or See the NTTPRI Release Notes for Generic V4.2 FSR00 PUN23 and higher, P/N 63105350142	N	N

Note: If you are missing any of the documents you need for your upgrade, contact the Summa Four Customer Response Center (CRC) by sending E-mail to tech_sup@summa4.com with "Attn: CRC Help Desk" in the subject heading. Or call the CRC at 1-800-978-6624 (or 603-695-1293). Fax 603-641-6238.

Table 2.3: North American Feature Package Firmware Requirements¹

Card Name	Firmware	Checksum	Vers.	Location	Changed Since V4.2 FSR00 PUN 25?	Changed Since V4.2 FSR00?
DCC	DCC	0000A575	2.02	U2	N	N
	LIN/PCM 0 DB	0000B9A2	1.00	U43	N	N
	LIN/PCM -3 DB	0000AB04	1.00	U44	N	N
	PCM/LIN Odd	0000AFA2	1.00	U33	N	N
	PCM/LIN Even	0000B736	1.00	U34	N	N
DTG/DTG-2	DTG-FW (See Note 2 below)	00007C30	1.25 ²	U2	Y	N
		000077AD	1.23 ²	U2	N	N
	Tone Odd	00000078	2.04	U54	N	N
	Tone Even	00004217	2.04	U53	N	N
	MAP PROM LP87	0000628A	1.1	U36	N	N
	MAP PROM LP88	00004B9E	1.1	U37	N	N
CPA	CPA	0000A7A2	1.03	U2	N	N
MFCR2	See Note 1					

Notes:

¹For firmware supporting other Summa Four Country Feature Packages see the Master Configurator Release Notes, 63098350133.

²Version 1.23 or 1.25 required. Version 1.25 differs by supplying an additional tone for Canadian customers.

2.5 SOFTWARE REQUIREMENTS

Valid software checksums and versions for the Generic V4.2 FSR00 PUN 26 software are listed in Table 2.4. Valid software checksums and versions for optional products are listed in Table 2.5.

Use the Software/Firmware Configuration utility to identify the version and checksum of each software file installed on the system (refer to the *System Administrator's Guide* for more information). Generic software files are distributed across the installation floppy diskettes. Each optional software product is contained on a single floppy diskette.

Table 2.4: V4.2 FSR00 PUN 26 Software Requirements

Software Product Name	Filename	Check-sum	File Vers.	Changed since V4.2 FSR00 PUN 25?	Changed since V4.2 FSR00?
GENERIC V4.2 FSR00 PUN 26	GLOBALS.EXE	01545CFB	4.04	Y ¹	Y
	HOSTMGR.EXE	021F5557	4.04	Y ¹	Y
	SYSWD.EXE	00000000	4.04	N	N
	REDMGR.EXE	00F0DF33	4.04	Y ¹	Y
	PERMGR.EXE	00000000	4.04	N	N
	NETMGR.EXE	0281E0BC	4.04	Y ¹	Y
	SNMP.EXE	0508CB72	4.04	Y ¹	Y
	INSTALL.EXE	02189911	4.04	Y ¹	Y
	MVDCT1.DWN	00F2D33A	1.08	N	Y
	NBC.DWN	01095DE7	1.08	Y	Y
	SSC.DWN	006C84CB	1.00	N	N
	CPA.DWN	003079F3	8.09	N	N
	DVC.DWN	005ADA02	1.08	N	N
	IPRC.DWN	0022E1EA	1.04	N	N
	DTMF.DWN	00053D1A	2.02	N	N
	DNI.DWN	006EF8D7	1.01	N	N
	4XT1.DWN	00349052	1.49	N	Y
	4XE1.DWN	003773FA	1.39	N	Y
	VRTX OS	—	1.08	N	N
	IFX	—	1.11	N	N
TNX	—	1.45	N	N	

Note

¹*Checksum change only. Version remains the same.*

Table 2.5: V4.2 FSR00 PUN 26 Optional Products Software Requirements

Software Product Name	Filename	Check-sum	File Vers.	Changed since V4.2 FSR00 PUN 25?	Changed since V4.2 FSR00?
	Optional Product Release Note Reference				
ETHERNET	ETHERMGR.EXE	00007B0C	4.02	N	N
TELEROUTER	TELERTE.EXE	00007ADA	4.00	N	N
MOTOROUTER	MOTORTE.EXE	00007ADA	4.00	N	N
ISDN Options					
ISDN-NFAS	See ISDN-PRI/ISDN-NFAS Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63100950142			N	Y
ISDN-PRI	See ISDN-PRI/ISDN-NFAS Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63100950142			N	Y
NI-2	See NI-2 Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63101150142			N	Y
NTTPRI	See NTTPRI Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63105350142			N	Y
NTDASS2	See NTDASS2 Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63100450142			N ¹	Y
DPNSS	See DPNSS Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63100650142			N ¹	Y
NET5	See NET5 Release Notes (for Generic V4.2 FSR00 PUN23 and higher) P/N 63100550142			N ¹	Y

Note

¹Released for V4.2 FSR00 PUN23 and higher shortly after the initial release of PUN23.

Section 3

UPGRADING TO V4.2 FSR00 PUN 26

3.1 INTRODUCTION

This section describes the procedures for installing Generic V4.2 FSR00 PUN 26 on systems currently running any V3.3, V4.0, V4.1 version of the Generic software as well as any V4.2 Generic software released prior to V4.2 FSR00 PUN26.

To upgrade to V4.2 FSR00 PUN26 from any release earlier than V3.3, contact Summa Four Technical Support. Do not attempt an upgrade from any release earlier than V3.3 without first contacting Summa Four Technical Support.

Take special note of the following:

- Call Summa Four at 1-800-978-6642 (or 603-695-1293) if you are running a version of the Generic earlier than V3.3 FSR00.
- All systems are shipped with the 8Mb RAM/25 MHz CPU unless the 16Mb RAM/33MHz CPU is specially ordered. The 16Mb RAM/33 MHz CPU card became available as an option with V4.2 FSR00 PUN24 and higher.
- **This section provides detailed installation instructions for loading system software and upgrading hardware. Deviating from these instructions can result in lost data. Read all the material in this section prior to installing the software. If you encounter any problems during the installation, contact Summa Four Technical Support at the number listed above.**
- **If you are currently running a Generic with a version V4.2 FSR00 through V4.2 FSR00 PUN23 or V4.2 FSR00 PUN25, you may perform a Live Upgrade. The Live Upgrade procedure is described later in this section.**

DO NOT perform a Live Upgrade if you are currently running V4.2 FSR00 PUN 24 (see the fix for issue U804010005 in Section 1.8.4). Upgrading from V4.2 FSR00 PUN24 to V4.2 FSR00 PUN 26 must be done manually.

CAUTION: Upgrading to V4.2 on redundant systems with any card other than an NBC-3 configured in slot 2 of the Master Port Subrack, can cause the CPU to crash during the reboot after the data base conversion is performed. There is also a potential risk that the database cannot be converted back to its original state after the CPU crashes.

If you are upgrading from Generic V3.3 or earlier, you must replace your NBC card with an NBC-3 Rev C0ER or higher.

Before you upgrade your system, verify, through the Card Maintenance screen, the Card Alarm Display screen, and the System Alarms Display screen, that your NBC-3 card(s) is/are properly installed and configured in slots 1 (and 2) of the Master Port Subrack.

Before you upgrade your non-redundant system, verify, through the Card Maintenance screen, the Card Alarm Display screen, and the System Alarms Display screen, that **no** card of any type is installed and configured in slot 2 of the Master Port Subrack.

3.2 PREPARING FOR THE SOFTWARE UPGRADE

There are two ways you can perform an upgrade: a manual procedure and an automated procedure (Live Upgrade). Live Upgrade is possible only on systems running Generic V4.2 FSR00 PUN00 or later (with the exception of V4.2 FSR00 PUN24).

Before you begin the software upgrade to V4.2 FSR00 PUN26, you need to first complete the following site prep checklist to ensure a successful upgrade:

Software Upgrade Site Prep Checklist		
Task	Date Completed	Completed By
Gather all required documents for the upgrade. Section 3.2.1		
Verify file sizes. Section 3.2.2		
Verify the PUN26 Upgrade Kit provided by Summa Four. Section 3.2.3 (Verify the BOM against the completed Upgrade Kit Request form. Verify all diskettes, firmware, and hardware (cards))		
Determine the hardware and firmware updates to be done before, during, or after the upgrade (manual or Live Upgrade). Section 3.2.4		
Identify the necessary peripheral equipment (consoles, diskettes, etc.). Section 3.2.5		
Verify a properly functioning update channel and/or other special system considerations. Section 3.2.6		

3.2.1 Additional Required Documents

Before you install the software, make sure you are familiar with, and have on-hand at the time of upgrade, the material contained in this section.

Note: If you are missing any of the documents you need for your upgrade, contact the Summa Four Customer Response Center (CRC) by sending E-mail to tech_sup@summa4.com with "Attn: CRC Help Desk" in the subject heading. Or call the CRC at 1-800-978-6624 (or 603-695-1293). Fax 603-641-6238.

- CPU Upgrade Procedure 63104050100 (if you have purchased the 16MB RAM/33 MHz CPU)
- If you are running any type of Summa Four ISDN software, you should have a copy of the applicable release notes. See Section 2, Table 2.5, for the part number(s) of these release notes.

Make a note of the part number. To download these documents (in .pdf format) from the Summa Four web site, go to <http://www.summa4.com/support/library.htm>. Click on the part number/title.

- The V4.2 Documentation Set for SDS and VCO Hardware and Software (seven volumes total: Hardware volumes 1, 2, 3, and 4; and Software volumes 1, 2, and 3).
- Product supplements for optional software, including:

Optional Software Supplements	
Software Product Name	Applicable Reference
Ethernet	<i>Ethernet Supplement</i>
Telerouter	<i>TeleRouter Reference Guide</i>
Motorrouter	Release Notes, P/N 63101750142
ISDN-PRI ISDN-NFAS	<i>ISDN Supplement</i>
NI-2	<i>NI-2 Supplement</i>
NTTPRI	<i>Japanese ISDN (NTTPRI) Supplement</i>
NTDASS2	<i>DASS2 Supplement</i>
DPNSS	<i>DPNSS Supplement</i>
NET5	<i>ISDN NET5 Supplement</i>
MIB	<i>VCO V4.2 Management Information Base (MIB) Reference Guide</i> <i>VCO V4.2 Management Information Base (MIB) User's Guide</i>
Country Feature Package	<i>Applicable Country Supplements</i>
IPRC	<i>IPRC Supplement and IPRC User's Guide</i>

3.2.2 Determining File Sizes

Because of some variations in existing installations, you may have difficulty converting from your current database to V4.2 FSR00 PUN26. To determine if this is the case, you need to know the size of several of your files. To determine the file sizes, use the Show Directory option in the Disk Utilities menu to display the files in the c:/dbase directory. The sizes of your files should match the file sizes in Table 3.1.

Table 3.1: File Sizes

Version Number ¹	File Name					
	syscnfg.tbl	dbvers.tbl	card.tbl	port.tbl	resgroup.tbl	promptlb.tbl
V3.3 FSR00	2081	288	32046	93184	2016	1120
V3.3 FSR01	2081	288	32046	93184	2016	1120
V3.3 FSR02	2160	288	32046	93184	2016	1120
V3.3 FSR03	2160	288	32046	93184	2016	1120
V3.3 FSR04	2160	288	32046	93184	2016	1120
V3.3 FSR05	2160	288	32046	93184	2016	1120
V3.3 FSR06	2160	288	32046	93184	2016	1120
V3.3 FSR06 PUN38	2160	288	32046	93184	2016	1120
V4.0 FSR00	2160	288	32046	93184	2016	1120
V4.0 FSR00 PUN22	2928	306	32046	158720	2016	1120
V4.0 FSR01	2928	306	32046	158720	2016	1120
V4.0 FSR02	2928	306	32046	158720	2016	1120
V4.1 FSR00 PUN22	3394	306	32046	158720	2016	1120
V4.2 FSR00	3394	324	32046	158720	2016	1120
V4.0 FSR02 PUN23	3394	324	32046	158720	2016	1120
V4.0 FSR02 PUN25	3394	324	32046	158720	2016	1120

Note:

¹*If you are running a version of software that is not in Table 3.1, then refer to the next lower version in the table and contact Summa Four Technical Support to determine the baseline Generic for your software.*

If the size of any of these files does not match the size listed in Table 3.1, contact Summa Four Technical Support immediately. Failure to have Technical Support evaluate the file size inconsistency will result in problems converting your current database to the V4.2 FSR00 PUN26 format.


3.2.3 V4.2 FSR00 PUN26 Upgrade Kit Inventory

Inventory your Upgrade Kit. It will consist of some or all of the following software, hardware, or firmware items.

Note: The Upgrade Kit that has been shipped to you is based on a completed Upgrade Request Form, originally submitted by someone in your company. If you do not have a copy of this completed form, contact the Summa Four Customer Response Center (CRC) by sending E-mail to tech_sup@summa4.com with "Attn: CRC Help Desk" in the subject heading. Or call the CRC at 1-800-978-6624 (or 603-695-1293).

Software:

- Five (5) diskettes labeled as follows:



Note: The x is a number from 1 to 5. The number indicates the sequence in which the diskettes must be loaded when you install the generic software.

- Optional Product Software diskettes that you specified on your Upgrade Request Form as having already purchased (see Section 2, Table 2.5 for a complete list of optional product software).

Note: If you are entitled to the Ethernet disk, then you are automatically shipped the MIB disk with this upgrade kit. Do not install the MIB disk onto your Summa Four switch. The MIB software is to be installed on your Network Management Workstation only. See Section 3.6 for instructions on installing the MIB disk.

Hardware:

- NBC-3 card, Rev C0ER (or later) or E0AR (or later)—two cards for redundant systems—if Summa Four determined that you require new NBC cards
- SWI card (two cards in a redundant system), Rev A0AR (or later)—if Summa Four determined that upgrading your SWI card is required.

Note: SWI cards at Revision A0AR (or later) are labeled SWI (underlined) on the front of the card.

- AAC card, Rev C0UR (or later)—if Summa Four determined that upgrading your AAC card is required.

Firmware

- 8Mb (68030) CPU firmware V4.04 (one ODD, U15; and one EVEN, U1)—if Summa Four determined that upgrading your 8Mb CPU card is required
- NBC-3 Boot firmware V1.02—if Summa Four determined that upgrading your NBC-3 is required
 - for card Revision C0ER the firmware position is U4
 - for card Revision E0AR the firmware position is U1

Note: Firmware supplied by Summa Four in this upgrade kit may be labeled U1, U4, or U1/U4. Regardless of the label, install the firmware in the position appropriate to the card Revision as shown above.

- NBC-3 EPLD firmware Version LP140C or higher (one piece, U73)—if Summa Four determined that upgrading your NBC-3 is required.

Note: This applies only to Rev E0AR (or later) cards. If you have a C0ER (or later) NBC-3 card, then you will not install this firmware.

- You may have received other firmware not listed in this subsection. To account for this firmware, compare your Upgrade Request Form with the firmware requirements listed in Section 2 of these release notes.

The *Card Maintenance* screen displays the current version of the prompts on your cards. This screen is accessed from the Menu. Refer to the *System Administrator's Guide* for additional information.

3.2.4 Updating Hardware and Firmware

Depending on whether you perform the Manual Upgrade procedure or the Live Upgrade procedure, exactly when you replace each hardware and/or firmware component is specified in *Table 3.2* and *Table 3.3*. Each component will be upgraded either before, during, or after the upgrade procedure.

Table 3.2: Upgrading Hardware & Firmware (Cards in Your System Before Upgrade)

Card	Note	Refer to:	When to Install Component	
			Manual Procedure	Live Upgrade Procedure
CPU (8Mb)	You must update the firmware on the CPU card if you are at any version before V4.2 FSR00.	Refer to Section 2 for the checksum, version, and the location of the firmware to be updated. ¹	During Upgrade	
CPU (16Mb)	No firmware updates required.	Refer to Section 2 for checksum and version.	After Upgrade	
SWI	You must update your SWI card if it is prior to Rev A0AR.		Before Upgrade	

Table 3.2: Upgrading Hardware & Firmware (Cards in Your System Before Upgrade) (Continued)

Card	Note	Refer to:	When to Install Component	
			Manual Procedure	Live Upgrade Procedure
AAC	You must update your AAC card if it is prior to Rev C0UR.		Before Upgrade	
NBC (Customers running V3.3 systems with NBC cards)	V4.2 does not support the NBC card; only the NBC-3 card is supported by V4.x systems. If you currently have an NBC card, you must upgrade to the NBC-3 card. <i>Note:</i> <i>The new NBC-3 card supports the DTG-2 mezzanine card.</i> Your system can operate with an NBC-3 card and your current DTG card, or with the new NBC-3/DTG-2 card combination. The NBC-3 card is a hot swap card: it can be removed and replaced while the system is powered up.	The <i>Technical Description: Network Bus Controller 3 (NBC-3) Card</i> in your hardware volume set — for instructions on installing the NBC-3 card. <i>Note: If you are upgrading from the NBC card, make certain to following the removal instructions for the NBC card. Do not remove the NBC card while the system is powered up.</i>	During Upgrade	N/A
NBC-3 (Rev C0ER or greater)	The NBC-3 card firmware must be updated if you are at any version before V4.2 FSR00.	Refer to Section 2 for the checksum, version, and the location of the NBC-3 firmware to be updated. ¹	During Upgrade	
4XT1		Refer to Section 2 for the checksum, version, and the location of the 4XT1 firmware to be updated. ¹	Before Upgrade	During Upgrade
4XE1		Refer to Section 2 for the checksum, version, and the location of the 4XE1 firmware to be updated. ¹	Before Upgrade	During Upgrade
E1		Refer to Section 2 for the checksum, version, and the location of the E1 firmware to be updated. ¹	Before Upgrade	During Upgrade

Table 3.2: Upgrading Hardware & Firmware (Cards in Your System Before Upgrade) (Continued)

Card	Note	Refer to:	When to Install Component	
			Manual Procedure	Live Upgrade Procedure
E1-PRI		Refer to Section 2 for the checksum, version, and the location of the E1-PRI firmware to be updated. ¹	Before Upgrade	During Upgrade
E1-PRI 120 ohm	If you have this card, Revision A0BR or earlier, you must swap this for an A0CR, or higher, card to avoid CRC errors.	Refer to Section 2 for the checksum, version, and the location of the E1-PRI firmware to be updated. ¹	Before Upgrade	During Upgrade
Check all Release Notes for any other changes.				

Notes:

¹ *Section 2 lists firmware location by U number. The card's technical description graphically shows the physical location of the firmware on the card. Firmware and EPLD removal and replacement procedures are contained in Appendix A.*

Table 3.3: Installing New Cards (if Included in the Upgrade Kit)

Card	Note	Refer to:	When to Install Component	
			Manual Procedure	Live Upgrade Procedure
NBC-3 (Rev E0AR or greater)	<p>The new NBC-3 card supports the DTG-2 mezzanine card. Your system can operate with an NBC-3 card and your current DTG card, or with the new NBC-3/DTG-2 card combination. The NBC-3 card is a <i>hot swap</i> card: it can be removed and replaced while the system is powered up.</p> <p><i>Note: Depending on your configuration, the NBC-3 card may be a new card. Some customers may have already upgraded to the NBC-3. If you already have an NBC-3 card installed in your system, you may need to update the firmware, (see Table 3.2). You may also opt to install the DTG-2 mezzanine card on your NBC-3 (refer to DTG-2 Card information in this table).</i></p>	<p><i>Technical Description: Network Bus Controller 3 (NBC-3) Card</i> in your hardware volume set — for instructions on installing the NBC-3/DTG-2 card.</p> <p><i>Note: If you are upgrading from the NBC card, be sure to follow the removal instructions for the NBC card. Do not remove the NBC card while the system is powered on.</i></p>	<p>During Upgrade</p> <p>(If upgrading from V3.x you must do a manual upgrade)</p>	<p>During Upgrade</p>
CPU (16Mb)	No firmware updates required.	Refer to Section 2 for checksum and version.	Swap After Upgrade	

Table 3.3: Installing New Cards (if Included in the Upgrade Kit) (Continued)

Card	Note	Refer to:	When to Install Component	
			Manual Procedure	Live Upgrade Procedure
DTG-2	<p>If you have an NBC-3 card, you may opt to purchase and install the DTG-2 mezzanine card on your current NBC-3.</p> <p>The DTG-2 is optional for SDS-1000 and VCO-80 systems. Your system can operate with an NBC-3 card and your current DTG card, or with the new NBC-3/DTG-2 card combination.</p> <p>The DTG-2 is required for VCO-20 systems.</p>	<p><i>Technical Description:</i> <i>Digital Tone Generator 2 Mezzanine (DTG-2) Card</i> in your hardware volume set — for instructions on installing the DTG-2 mezzanine card.</p>	During Upgrade	
E1-PRI 120 ohm (optional)	<p>If you have this card, Revision A0BR or earlier, you must swap this for an A0CR, or higher, card to avoid CRC errors.</p>	<p><i>Technical Description:</i> <i>E1-PRI Card</i> in your hardware volume set.</p>	Install card Before Upgrade	Install card During Upgrade

3.2.5 Other Necessary Items You Will Need for an Installation

You will need to have the following additional material, tools, and equipment available for your upgrade:

Material and Tools:

- Blank diskettes for database and log file backup:
Four blank diskettes—if you are doing a Manual Upgrade
Six blank diskettes—if you are doing a Live Upgrade
- Firmware chip remover
- EPLD chip remover (supplied by Summa Four as part of the Upgrade Kit)

Equipment:

- System printer, so you have a printed record of the installation process.
- For redundant systems, be sure you can connect a system console to both system controllers. Depending on your equipment’s arrangement, you can:
- Set up a separate system console for each controller (A- and B-side).

- Use an A/B transfer switch wired to both system controller CPU-TM front panels to switch access.
- Physically remove and reconnect the system console cable from one CPU-TM front panel to the other.

3.2.6 Special System Considerations

Observe the following precautions.

All Systems:

Verify, via the Card Alarms Display, and the log file, that there are no Fatal or Critical alarms currently on the system. Determine if Major and Minor alarms will have an effect on the upgrade. The alarms are explained in Appendix D in the *System Administrator's Guide*.

If you are upgrading from Generic V3.3 or earlier, you must replace your NBC card with an NBC-3 Rev C0ER or higher.

Before you upgrade your system, verify, through the Card Maintenance screen, the Card Alarm Display screen, and the System Alarms Display screen, that your NBC-3 card(s) is/are properly installed and configured in slots 1 (and 2) of the Master Port Subrack.

Non-redundant Systems:

Before you upgrade your non-redundant system, verify that no card of any type is installed and configured in slot 2 of the Master Port Subrack.

Redundant Systems:

Upgrading to V4.2 on redundant systems with any card other than an NBC-3 installed in slot 2 of the Master Port Subrack, can cause the CPU to crash during the reboot after the data base conversion is performed. There is also a potential risk that the database cannot be converted back to its original state after the CPU crashes.

Note: On redundant systems any alarm containing the words "Update Channel" or "UPD" must be resolved before attempting an upgrade.

3.3 LIVE UPGRADE PROCEDURE

The Live Upgrade feature provides the ability to update software on a redundant VCO-20, VCO-80, or SDS-1000 system without loss of calls, and with a minimum reduction in capacity. The procedure consists of installing the new software, updating the system controller (CPU card) and/or NBC-3 card and/or DTG/DTG-2 cards (if needed), then switching over to the new release, and finally, updating certain network and service circuit cards (if needed).

Notes:

The Live Upgrade feature must be installed on a switch before a Live Upgrade to a subsequent release can be performed. Because the Live Upgrade feature is included with V4.2 FSR00 and higher, it can be used to upgrade to future versions of the Generic.

Live Upgrade cannot be performed on a switch running V4.2 FSR00 PUN24.

You can abort the process at any time and restore the prior version up to the time when the active controller is running the new release of software. To revert to the prior release of software *after* the active controller is running the new software, you must perform a non-live (manual) installation of the prior release.

Notes:

Live Upgrade applies only to the Generic software; it does not does not upgrade Summa Four SS7 software.

3.3.1 Preparing for Live Upgrade

Note the following when performing a live upgrade:

- Calls can be continued during the upgrade.
- Live Upgrade can be performed only on a redundant system. Non-redundant systems must be upgraded with the Manual Upgrade procedure (see Section 3.4).
- The switch will operate in a non-redundant mode during much of the Live Upgrade procedure. This period of non-redundancy has been minimized as much as possible.

Note: When upgrading software on the SDS/VCO, the software is upgraded on the CPU. The active or standby side of a system refers to the CPU or controller.

- The system administrator is prevented from modifying the configuration of the switch during the Live Upgrade procedure.
- If the upgrade includes hardware, firmware, or software for a card that is a *single resource*, there may be an interruption of service that is provided by that resource.
- Perform the live upgrade when call traffic is lowest; the switch cannot operate at full capacity during the live upgrade. Also note that, should the live upgrade fail, upgrading during low volume periods would affect the least number of calls.
- 20 MB disk space must be available on each controller's hard drive to perform the live upgrade. See the *System Administration Guide*, Section 4 (Maintenance), Disk Utilities, Show Free Disk Space.

The Live Upgrade procedure will automatically check the free space on both hard drives and if there is a shortage of space, it aborts the Live Upgrade and reports the problem to the Regular Log file as well as to the Live Upgrade log file. Live Upgrade log file error messages and corrective action are contained in *Appendix B*. Regular log file error messages and corrective action are contained in the *System Administrator's Guide*, *Appendix D*.

- Modifications to the database are not allowed during the live upgrade. You should not remove cards from the switch unless directed to do so as part of the upgrade process.

- Control of the upgrade may be done via:
 - *Local Console via serial port (Administration Console)*
 - *Telnet session (Ethernet)*
 - *Modem port*

Note: Hardware and/or firmware updates require on-site personnel. In this case, the live upgrade cannot be done remotely.

- If you are planning to replace the AAC card, and/or SWI card, and/or install the 16Mb/33Mhz CPU, do not do these card swap-outs during the Live Upgrade. (See Section 3.2.4.)
- All log information about the live upgrade is sent to the Regular log file and to the Live Upgrade log file (of both hard drives). Also, "Prompt, Warning, and Error" messages will appear in the lower, right-hand corner of the screen when you execute various Live Upgrade steps from the Live Upgrade Control Menu.

The format of the Regular log file is C:/LOG/A-*mmdd*.LOG and C:/LOG/B-*mmdd*.LOG. These two file names will be on both hard drives. However, keep in mind that files A-*mmdd*.LOG and B-*mmdd*.LOG on the A-side's hard drive are different from files A-*mmdd*.LOG and B-*mmdd*.LOG on the B-side's hard drive.

The format of the Live Upgrade log file is C:/LOG/UG*mmddy*.LOG. This log is similar to the Regular log, but is written only during upgrade and reflects the upgrade in progress. Note that the filename contains the month, day, and year of the update in the format *mmddy*. The log file can be displayed and printed by choosing the Display/Print Upgrade Log menu option. This file name will be on both hard drives. However, keep in mind that the file UG-*mmddy*.LOG on the A-side's hard drive is different from file UG-*mmddy*.LOG on the B-side's hard drive.

For information on how to display the Regular log file on the screen, see the *System Administrator's Guide, Maintenance Section*.

For information on how to display the Live Upgrade log file on the screen, see this procedure.

Note: If a printer is connected to the system while the Live Upgrade is in progress, both the Regular log file and the Live Upgrade log file are printed. Live Upgrade log file messages appear indented with respect to the Regular log file messages.

Regular log file entries pertaining to Live Upgrade consist of an ALM15x message imbedded in an FRM5xx message.

Live Upgrade log file entries: (1) pertain only to Live Upgrade, (2) do not contain ALM15x and FRM5xx headers.

- The upgrade can be aborted up to the point where the Active CPU running the old version of the software switches control over to the Standby CPU running the new version of the software.
- New messages related to the live upgrade are contained in *Appendix B*.

3.3.2 Overview of the Procedure

To upgrade a system via Live Upgrade, you will be required to perform some or all of the four basic tasks (tasks 1 and 3 are mandatory).

1. Follow the Live Upgrade procedure to upgrade the software on both sides of the system. Install the Generic and optional software.
2. Update the CPU, and/or the NBC-3, and/or the DTG/DTG-2 if needed.
3. Switchover to the new software release.
4. Update certain Network cards and/or Service Circuit cards. if needed.

Access the Live Upgrade Control Menu from the Maintenance Menu, Live Upgrade option. This is illustrated in Figure 3.1.

```
          M A I N T E N A N C E      M E N U


A) Card Maintenance
B) Disk Utilities
C) Print/Display System Log File
D) Print/Display System Trace File
E) Switch ACT System To SBY
F) Master Timing Link Selection
G) Card Alarm Display
H) System Alarm Display
I) Shutdown System
J) Voice Prompt Maintenance
K) Core Dump
L) Live Upgrade Control

Enter Selection: _
```

TP000072

Figure 3.1: Live Upgrade on the Maintenance Menu

The Live Upgrade Control Menu is illustrated in Figure 3.2. Valid selections are limited to those appropriate for the current step as indicated in brackets "[]". For example, "Enter Selection [A,J,K]:".



TP000159

Figure 3.2: Live Upgrade Control Menu

To indicate that a live upgrade is in progress, the field displays UAC or USB. UAC indicates UpgradeActive mode, and USB indicates UpgradeStandBy mode. In Figure 3.2, side A is in standby mode and side B is active.

3.3.3 Access to Other Menus and Screens

To access the main menu and Maintenance menu from the Live Upgrade screen, do the following:

Main Menu Access

To access the Main Menu, press **Main Menu**.

Maintenance Menu

To access the Maintenance menu, press **Prev Menu** or **Exit**.

3.3.4 Overview of the Steps

An overview of the steps required to perform a live upgrade are listed below:

Step	Action (Live Upgrade Control Menu Option)
1	Prepare for the installation of the new release—Option A Directories that are needed for the process are created. The current release on each side of system is backed-up.
2	Backup the existing database on each side—Option H
3	Install the new software on each side—Option B The needed files are placed on both hard drives of the switch.
4	Prepare for the upgrade—Option C Takes place on the <i>initial</i> standby side. The system is set up to boot from the new release. Suitability of system to accept the release is checked.
5	Enable/disable/configure optional software on the standby side— Option D (e.g. Ethernet, ISDN, NFAS, Telerouter)
6	Update the generic—Option E The new release is booted on the standby side. A database conversion (if needed) is done automatically. A synchronization of dynamic information is done.
7	Switch the active side to standby—Option F <i>The other side will now be updated.</i> <i>Note: After this step is complete, the upgrade can no longer be aborted.</i>
8	Prepare for the upgrade—Option C Takes place on the <i>remaining</i> side. The system is set up to boot from the new release. Suitability of system to accept the release is checked.
9	Enable/disable/configure optional software—Option D (e.g. Ethernet, ISDN, NFAS, Telerouter)
10	Update the generic—Option E The new release is booted on the new standby side. A database conversion (if needed) is done. A synchronization of dynamic information is done.
11	Cutover of Port and Service Cards—Option G The port and service cards are switched-over.
12	Backup the new database—Option H
13	Clean-up—Option I
Upgrade to the 16Mb/33MHz CPU. See Section 3.5.	
Install MIB software. See Section 3.6.	

3.3.5 Performing a Live Upgrade

The following is a detailed explanation of the steps outlined in Section 3.3.4. Follow these steps to perform a live upgrade on your system.

3.3.5.1 Step 1: Prepare for the Installation of the New Release

Live Upgrade Control Menu: Option A—Prepare for Install

To initiate installation of both the Active and Standby sides, choose option A on the upgrade menu while logged into the A-side and then, again, while logged into the B-side.

The installation routine determines if the disk has enough free space to create a new directory structure and to store the new files. If a shortage of disk space is detected, you are notified and the upgrade is automatically aborted.

If you do not have enough free space to perform the upgrade and are unsure of the disk maintenance necessary to obtain it, contact Summa Four at 1-800-978-6642 (or 603-695-1293).

The directory structure that is required by the upgrade process is shown in Figure 3.3. The directories created for the upgrade procedure are shown in bold italic; they are automatically created by the Generic software automatically when you choose the Prepare for Install option. If they already exist, any existing files in these directories are deleted, but the directories themselves are maintained, for use during the upgrade process.




Figure 3.3: Directory Structure

Directory	Contents
C:/new/boot	New executable files, and download application files
C:/new/dbase	New, empty database
C:/old/boot	Current software release The current Generic software is restored from this directory if the Abort Upgrade option on the Live Upgrade Control menu is selected.
C:/old/dbase	Current database The current database is restored from this directory if the Abort Upgrade option on the Live Upgrade Control menu is selected.

This step must be performed on both controllers.

Abort option: The upgrade can be aborted at this time. Choose option J on the upgrade menu.

3.3.5.2 Step 2: Back Up the Existing Database

Live Upgrade Control Menu: Option H—Database Store (Backup)

To initiate a back up of the existing database, choose option H on the upgrade menu while logged into the A-side and then, again, while logged into the B-side.

You should back up your current database in case it is necessary to restore the previous generic software version from floppy disk. The backup database option on the Live Upgrade Control menu is similar to the manual database backup utility.

You will be automatically prompted with "Store from C:/ to A:/ YES/NO _".

Type Y for Yes.

Abort option: The upgrade can be aborted at this time. To abort, choose option J on the upgrade menu.

3.3.5.3 Step 3: Install the New Software

Live Upgrade Control Menu: Option B—Install New Release

After the new directories are created and a database backup performed, install the new Generic software onto both Active and Standby system controllers.

Install the new software from floppy disks, or from another host with FTP or FTP and PPP, if Ethernet or a modem connection is available. The files are copied to the sub-directories under the C:/new directory.

Perform Step 3 on *both* system controllers before proceeding to the next step. After completing Step 3 on both controllers, continue the upgrade process on the standby controller. No further activity is performed on the active controller until the standby controller has been upgraded.

Abort option: The upgrade can be aborted at this time. To abort, choose option J on the upgrade menu.

Installing from floppy disks

When you choose the Install New Release option on the Live Upgrade Control menu, the VCO Installation screen is displayed as shown in Figure 3.4.




Figure 3.4: VCO Installation Screen

To install from floppy disks, choose option 1. The VCO Floppy Installation screen is displayed; refer to Figure 3.5.




Figure 3.5: VCO Floppy Installation Screen

When you choose the floppy installation option you are prompted to insert the installation disks into the floppy drive so that the files can automatically be transferred into the appropriate directories. Pressing any key other than Enter or Return stops the loading of files from the floppy drive.

The floppy disk number is displayed in the VCO Floppy Installation screen; for example, Insert Generic Floppy 1. When the floppy is inserted the volume label is verified. Your response (for example, if you pressed the Enter key to continue) is logged in the upgrade log file along with the files that are being installed. If any files are missing from the floppy, or if there is a mismatch, the upgrade is aborted.

After all software disks have been installed, you are prompted to install optional software from the screen as shown in Figure 3.6. If no other software is to be installed, select option 2 as shown in Figure 3.6, and press the Enter key to exit the installation.

Optional software

After the Generic software is installed, you can install optional software package files; refer to Figure 3.6.

To install an optional software package select option 1.

After completing the installation of an option, the menu in Figure 3.6 appears again. Select option 1 again to install another software package, or select option 2 to terminate the installation.

In Step 5 (and in step 8 - on the remaining side) you will enable and configure the optional software.




Figure 3.6: Install from Floppy Screen

Installing from another host

If you install the software from a remote computer using FTP via ethernet, or PPP, you control the process from the FTP client. You are required to select the needed files and copy them to the appropriate subdirectories under the C:/new directory. This option assumes that the user knows how to FTP files from the host computer to the SDS/VCO system.

When the transfer of the new generic software to the hard disk using FTP is complete, you must indicate that the transfer is complete by selecting option 2 in the VCO Installation screen; refer to Figure 3.4 on page 19. The generic software then verifies that the transfer is complete. Successful transfer is indicated by the message: Check for all Files Successful.

3.3.5.4 Step 4: Prepare to Upgrade the First Side

Live Upgrade Control Menu: Option C—Prepare for Live Upgrade

On the Standby side of the system initiate step 4 by choosing option C.

During this step, the Generic software automatically verifies that:

- The side being upgraded in this step is in standby mode and that the alternate side is active and running.

- The file synchronization (static database and dynamic state information) has completed.
- The new software release has been placed in the C:/new directory on the hard drive and that all needed files are available for the upgrade.
- The version number of the software release being installed is newer than the current software release.
- The switch configuration is suitable for the upgrade.

Note: If the configuration is not suitable, information is logged and the upgrade is prohibited.

You are notified if there are single resources in the system that require updating. Note that updating a single resource causes a loss of capacity for that resource. Refer to *Appendix B* for Live Upgrade messages.

When verification of the preceding has been successfully completed, the **existing** Generic software and the switch configuration is copied to the C:/old directory. Finally, the Generic copies the new boot files from C:/new/boot into the current boot area, C:/boot. During this and later steps, you are prevented from making any configuration changes on the system.

Abort option: The upgrade can be aborted at this time. To abort, choose option J on the upgrade menu.

3.3.5.5 Step 5: Enable/Disable/Configure Optional Software

Live Upgrade Control Menu: Option D—Enable/Disable/Configure Optional S/W

This step is optional. If you do not have optional software, skip this step.

To initiate step 5, choose option D. The screen illustrated in Figure 3.7 is displayed.

Note that only the optional software packages that have been installed are shown.

This step consists of two parts: enabling the options and configuring the options.

```
      E N A B L E / D I S A B L E / C O N F I G U R E

      O P T I O N A L   S O F T W A R E

      A) Enable Ethernet
      B) Disable Telerouter
      C) Enable ISDN
      D) Enable NFAS
      E) Enable NI-2

      Enter Selection: _

#00 Fri Feb 13, 1998 16:41  A-USB B-UAC
```

TP000163

Figure 3.7: Enable/Disable/Configure Optional Software

You can enable or disable software depending on its current state. For instance, note in Figure 3.7 that the only software package enabled is Telerouter since the option for Telerouter is to Disable. All other options are to Enable, thereby indicating that the other software packages (Ethernet, ISDN, NFAS, NI-2) are currently disabled.

If Ethernet is enabled, you are prompted to set the parameters. The Ethernet configuration process is the same as the manual Ethernet configuration process.

Abort option: The upgrade can be aborted at this time. To abort, choose option J on the upgrade menu.

3.3.5.6 Step 6: Update the Generic

Live Upgrade Control Menu: Option E—Update Generic

Perform this step on the standby side of the switch. This step results in an update of the Generic software.

Note: The system is non-redundant from the time you start the update of one side (step 6) until the time that new release is running on both sides of the system. Once both sides are running the new release of software, the system returns to a redundant mode of operation.

When the Update Generic option is selected:

1. the standby side is rebooted
2. the new Generic does a database conversion (if needed)
3. a login screen appears on the console

Before initiating the update from V4.2 FSR00 (or subsequent PUN releases) to V4.2 FSR00 PUN26, update the firmware on the standby NBC-3. (Canadian customers will also need to update their DTG/DTG-2 cards.)

Updating the NBC-3 Card

An NBC-3 card that is in standby mode can be removed while the system is running.

Note that when the NBC-3 card is removed, a DTG-2 card mounted on that NBC-3 is consequently also removed and updated (see the following subsection). If the DTG-2 card is the only tone generator in the SDS/VCO, the system will experience a loss of tone generation resources while the NBC-3 and/or DTG-2 is upgraded. Refer to the *Technical Description: NBC-3* for removal and replacement procedures.

After restoring the NBC-3 card, reset the standby CPU via the Alarm Arbiter card.

Updating the DTG-2 Card

Note: An update from V4.2 FSR00 (or subsequent PUN releases) to V4.2 FSR00 PUN26 only Canadian customers require a DTG update.

You must take the DTG-2 out-of-service (OOS) when its firmware or hardware is updated.

The DTG-2 mounted on the standby NBC-3 should be upgraded, even if it is the active tone card. If your SDS/VCO has redundant tone cards, assure that the DTG-2 card on the standby NBC-3 is in standby mode. If the system does not have redundant DTG-2 cards, note that the system will experience a loss of tone generation resources while the DTG-2 is upgraded.

To initiate step 6, choose option E.

When you upgrade your Generic via Live Upgrade, an automatic database conversion is performed as a part of the upgrade.

Database Conversion

When the new Generic is running, a database conversion is automatically performed by the software. The converted files are updated in the C:/dbase directory and loaded into memory as the static portion of the new database. Any new tables needed for the upgrade are obtained from the C:/new/dbase directory. Note that some upgrades may *not* require a database conversion.

Abort option: The upgrade can be aborted at this time. To abort, choose option J on the upgrade menu.

3.3.5.7 Step 7: Switch the Active Side to Standby

Live Upgrade Control Menu: Option F—Switch to Standby

In step 7, the active side (controller) is placed in standby mode. When this is done, the previously active side, running the old generic software, becomes available to upgrade. In addition, the side which was in standby mode will become active *and be running the new software*.

Note: Make certain your console is on the active side of the SDS/VCO when performing the switchover.

To initiate this step, *on the active side of the system*, choose option F.

Once the switchover has taken place—the reboot and NBC download completes, your console should be on the standby controller's side (the controller that needs to be updated).

Abort option: When this step is initiated, the upgrade can no longer be aborted. If restoring the old software release is required, you must perform a traditional reinstallation of the original software.

3.3.5.8 Step 8: Prepare to Upgrade the Remaining Side

Live Upgrade Control Menu: Option C—Prepare for Live Upgrade

On the new Standby side of the system initiate step 8 by choosing option C.

During this step, the Generic software automatically verifies that:

- The side being upgraded in this step is in standby mode and that the alternate side is active and running.
- The file synchronization (static database and dynamic state information) has completed.
- The new software release has been placed in the C:/new directory on the hard drive and that all needed files are available for the upgrade.
- The version number of the software release being installed is newer than the current software release.
- The switch configuration is suitable for the upgrade.

Note: If the configuration is not suitable, information is logged and the upgrade is prohibited.

You are notified if there are single resources in the system that require updating. Note that updating a single resource causes a loss of capacity for that resource. Refer to *Appendix B* for Live Upgrade messages.

When verification of the preceding has been successfully completed, the **existing** Generic software and the switch configuration is copied to the C:/old directory. Finally, the Generic copies the new boot files from C:/new/boot into the current boot area, C:/boot. During this and later steps, you are prevented from making any configuration changes on the system.

Abort option: The upgrade can no longer be aborted.

3.3.5.9 Step 9: Enable/Disable/Configure Optional Software


Live Upgrade Control Menu: Option D—Enable/Disable/Configure Optional S/W

This step is optional. If you do not have optional software, skip this step.

To initiate step 9, choose option D. The screen illustrated in Figure 3.8 is displayed.

Note that only the optional software packages that have been installed are shown.

This step consists of two parts: enabling the options and configuring the options.



TP000163

Figure 3.8: Enable/Disable/Configure Optional Software

You can enable or disable software depending on its current state. For instance, note in Figure 3.7 that the only software package enabled is Telerouter since the option for Telerouter is to Disable. All other options are to Enable, thereby indicating that the other software packages (Ethernet, ISDN, NFAS, NI-2) are currently disabled.

If Ethernet is enabled, you are prompted to set the parameters. The Ethernet configuration process is the same as the manual Ethernet configuration process.

Abort option: The upgrade can no longer be aborted.

3.3.5.10 Step 10: Update the Generic

Live Upgrade Control Menu: Option E—Update Generic

Perform this step on the standby side of the switch. This step results in an update of the Generic software.

Note: The system is non-redundant from the time you start the update of one side (step 6) until the time that new release is running on both sides of the system. Once both sides are running the new release of software, the system returns to a redundant mode of operation.

When the Update Generic option is selected:

1. the standby side is rebooted
2. the new Generic does a database conversion (if needed)
3. a login screen appears on the console

Before initiating the update from V4.2 FSR00 (or subsequent PUN releases) to V4.2 FSR00 PUN26, update the firmware on the standby NBC-3. (Canadian customers will also need to update their DTG/DTG-2 cards.)

Updating the NBC-3 Card

An NBC-3 card that is in standby mode can be removed while the system is running.

Note that when the NBC-3 card is removed, a DTG-2 card mounted on that NBC-3 is consequently also removed and updated (see the following subsection). If the DTG-2 card is the only tone generator in the SDS/VCO, the system will experience a loss of tone generation resources while the NBC-3 and/or DTG-2 is upgraded. Refer to the *Technical Description: NBC-3* for removal and replacement procedures.

After restoring the NBC-3 card, reset the standby CPU via the Alarm Arbiter card.

Updating the DTG-2 Card

Note: An update from V4.2 FSR00 (or subsequent PUN releases) to V4.2 FSR00 PUN26 only Canadian customers require a DTG update.

You must take the DTG-2 out-of-service (OOS) when its firmware or hardware is updated.

The DTG-2 mounted on the standby NBC-3 should be upgraded, even if it is the active tone card. If your SDS/VCO has redundant tone cards, assure that the DTG-2 card on the standby NBC-3 is in standby mode. If the system does not have redundant DTG-2 cards, note that the system will experience a loss of tone generation resources while the DTG-2 is upgraded.

To initiate step 10, choose option E.

When you upgrade your Generic via Live Upgrade, an automatic database conversion is performed as a part of the upgrade.

Database Conversion

When the new Generic is running, a database conversion is automatically performed by the software. The converted files are updated in the C:/dbase directory and loaded into memory as the static portion of the new database. Any new tables needed for the upgrade are obtained from the C:/new/dbase directory. Note that some upgrades may *not* require a database conversion.

Verifying File Synchronization

For redundant systems, after you have installed the software on both sides and rebooted the system, you must verify that file synchronization has occurred. Check the messages in the log file and verify that:

```
RED32:ACT FILE SYNC COMPLETED
```

from the ACT side, and

```
RED20:SBY FILE SYNC COMPLETED
```

from the SBY side, appear.

When file synchronization has been verified, the installation of system software is complete. Proceed to the next section to install the MIB software if you have a Network Management System.

Abort option: The upgrade can no longer be aborted.

3.3.5.11 Step 11: Cutover of Port and Service Cards

Live Upgrade Control Menu: Option G—Cutover Port and Service Cards

Once the new release is running on both sides of the system and the file sync is complete, cut over the port and service cards that need to be upgraded, from the active side of the system.

To initiate step 8, on the active side of the system, choose option G. When the Cutover Port and Service Cards option is selected, the Card Cut-Over screen is displayed. See Figure 3.9. This screen lists the cards needing an upgrade, and the type of upgrade (hardware, firmware, or software) that is needed.

You can control the card cutover by choosing the ordering and timing for the upgrade of the cards on the Card Cut-Over screen. You can select to upgrade a single card or several cards at a time; this depends on the call handling capacity that is to be maintained on the system. Take cards out of service and, if needed, upgrade the firmware or hardware and then place the card back in service. The new application (if applicable) is downloaded onto the card when it is placed back in service.

You do not have to wait until a card is completely OOS before starting the cutover process on another card. The OOS and Activate options operate on a single card, not a group of cards.

If you try to take the last active card of a resource type (the only card or the last active card of a group) out of service, the system notifies you and requests confirmation prior to performing the request. Refer to *Appendix B* for a list of prompts, warnings and error messages.

```

                                C A R D       C U T - O V E R

RLSI      CARD TYPE                UPG      VERS      VERS      S
-----
1  1  3   Tone Generator           -F-      1.23     -----   A
1  1  4   Tone Generator           -F-      1.23     -----   S
1  1 10   Four Span T1 Card        HFS      1.00     1.20      G
1  1 14   MVDC-T1 Trunk            --S      -----   -----   O
1  1 15   MVDC-T1 Trunk            --S      1.02     1.68      A

ACTIVATE, GRACEFUL-OOS, OR FORCE-OOS (A, G, F) ____

RLS 1 1 10   Being Gracefully Idled
#00 Fri Feb 13, 1998 16:55 A-USB B-UAC

```

TP000164

Figure 3.9: Card Cut-Over

The Card Cut-Over screen can display up to fourteen cards. There can be up to eleven screens, which can be navigated by pressing the Prev Screen key and the Next Screen key. To leave the Card Cut-Over screen without making any changes, press the Exit, Prev, Menu or Main Menu key. No changes are made unless Enter is pressed.

Field Definitions

The **RLSI** column contains the physical location of the card; rack, level, slot and interface that needs upgrading.

The **Card Type** column indicates the type of card in the location indicated in the corresponding column.

The **UPG** (upgrade) column contains information on the type of upgrade needed on the corresponding card. The UPG indicators are:

- F** firmware update needed
- H** hardware update needed
- S** software update needed

The **FIRM VERS** column displays the current firmware version.

The **D/L VERS** column displays the current download version. If the card does not support a download, the field contains four dashes.

Note that the version number (**FIRM VERS** and **D/L VERS**) information is not available when the card is out of service (O).

The **S** column on the far right of that screen, indicates the status of the card, as noted below.

- A** Active — ports on this card can be involved in active calls, and can be allocated to new calls.
- S** Standby — valid for DTG (not DTG-2) cards or redundant BRC cards.
- G** Graceful idling (graceful-OOS) — ports on this card are currently involved in active calls, but cannot be allocated to new calls. The card remains in this mode until all ports are idle. The card then is placed OOS.

The card remains in a status of G until the card is OOS, at which time the G status changes to a status of O.
- O** Out-of-service (OOS) — no ports on this card are currently involved in active calls, and they cannot be allocated to new calls.

Card Cut-Over Options

The bottom of the screen contains the data entry field:

ACTIVATE, GRACEFUL-OOS, OR FORCE-OOS (A, G, F): __

The options for this field are explained below.

Activate (A)

If you choose option A the card is placed back in service. This causes an application download upgrade on the card, if appropriate. The Generic also verifies that the version number for the firmware is compatible with the application download for the card. If not compatible, you are notified and the activation is prohibited.

Once the card is active again, it is removed from the list in the Card Cut-Over screen, and information is written to the log file to indicate that the card has been upgraded. This information is sent to the standby side via the update channel so that both sides have current information about the status of the cards.

Graceful-OOS (G)

If you choose option G, all idle ports are taken out of service (OOS). The Generic waits for active ports to become idle before taking them out of service. Once all ports are idle, the card state is set to OOS. Until the card's status is O, indicating the card is out-of-service, the card is still involved in active call processing. This command may take some time to complete, depending upon the duration of the active calls using the card.

Force-OOS (F)

If you choose option F, the Generic tears down any active calls and places the card OOS (out-of-service). If you select this option, you must press the Enter key a second time, to confirm that this is what you want to do.

You can upgrade a card once the card state is OOS. You can remove cards which require firmware and/or hardware upgrades from the switch and update them after placing them in OOS. You can upgrade cards which require only a software upgrade by simply activating the card.

When both sides of the system are running the new software release, you can change the configuration of the system. This may be needed to modify the setup of cards to take advantage of new features and capabilities. It is strongly recommended however, that non-upgrade related changes *not* be made until the upgrade process is complete. This helps to isolate any potential problems.

Abort option: The upgrade can no longer be aborted.

3.3.5.12 Step 9: Backing Up the New Database

Live Upgrade Control Menu: Option H—Database Store (Backup)

Step 9 involves the backup of the new database. This is done if there was a database conversion resulting in a changed format.

To initiate step 9, choose the option H. This option is the same as the Database Store option on the Disk Utilities menu. Refer to the *System Administration Guide* for further information.

You can also use the Copy Files option in the Disk Utilities menu, or FTP operations from a remote system, to store the database in an alternate location.

3.3.5.13 Step 10: Clean-up

Live Upgrade Control Menu: Option I—Post Live Upgrade Cleanup

To initiate the clean-up, choose option I.

- This step is not permitted until both sides are running the new software release
- Clean up should not be performed until card cutover has been completed.

When this option is selected, the Generic removes the files from the C:/old and the C:/new directory trees.

Once you have updated both sides of your switch via Live Upgrade, proceed to *Section 3.6, Installing the MIB Software*, on page 44.

3.4 MANUAL UPDATE PROCEDURE

Note: To perform a manual upgrade of the system and/or optional software, you must take both redundant and non-redundant systems off-line for a brief period.

To manually upgrade a system you must perform six tasks.

1. Database backup and system power down (Section 3.4.1)
This is a precaution against any possible loss of data.
2. System software installation (Section 3.4.4)
Install the Generic and optional software.
3. Database conversion (Section 3.4.5)
Update the database tables.
4. Install software on the B-side (Section 3.4.6)
Redundant systems only.
5. Upgrade to 16Mb/33MHz CPUs (optional) (Section 3.5)
6. Host software installation (Section 3.6)
Install the MIB on your network management system.

Each of these tasks is organized as a separate section. Because redundant systems require software installation on both sides, and because the optional software varies from customer to customer, there will very likely be a slightly different path for each upgrade. If you follow the instructions sequentially and perform the tasks as they apply to your system, you will be assured of a successful upgrade.

As you perform the upgrade, note that task 3, system software installation, is more detailed because it also deals with optional software installation.


3.4.1 Backing up the Database and System Power Down

Back up the database prior to beginning this installation. Do not try to back up the system database during the installation or after replacing the hardware and firmware.

NOTE: During normal system operation, use the Data Base Store functions on the Disk Utilities menu to back-up the system data base. For more information about the Disk Utilities menu, refer to the System Administration Guide.

To back-up the system data base, follow these steps.


1. Sign onto the system and access the Maintenance menu. (Refer to Figure 3.10)



TP000072

Figure 3.10: Maintenance Menu

2. Remove any diskette in the diskette drive on the A-side and insert a high-density diskette.
3. Type **B** to access the Disk Utilities, and press the **Return** key. The Disk Utilities menu appears (Refer to Figure 3.11.)



TP000096

Figure 3.11: Disk Utilities Menu

4. a. To format the diskette, type **I** and press the **Return** key.
The following message appears:

```
          F O R M A T   D I S K
```

```
Format What Drive? _____
Disk Volume Label? _____
Do Bad Sector Scan During Format <Y/N>? ____
```

The cursor is in the first field waiting for your response.
Appropriate responses to the prompts are provided below:

Format What Drive?

Type A:
then press the **Next Field** key.

Disk Volume Label?

This is optional. If you do not want to label the disk, press the **Next Field** key.
If you want to label the disk, type in the label name and then press the **Next Field** key.

Do Bad Sector Scan During Format
<Y/N>?

Type Y.
This is optional. If you do not want to scan the disk for bad sectors, type **N**.
Note: This field is required and cannot be left blank.

- b. A message appears to confirm your responses.
For example:

F O R M A T D I S K

Format Drive:

A:

OKAY TO FORMAT DISK? <Y/N>? ____

Type **Y** and then press **Enter**.

5. When the formatting is complete the Disk Utilities menu appears.
 - a. Type **E** for **Database Store** and press **Return**. The following message appears:

Ok to Store Database From C: to A: <Y/N>?

- b. Type **Y** and press **Return**. A message at the bottom of the screen indicates the copying is taking place.
6. When the copy is complete, the message in Step 5 above reappears. Press **Exit** to return to the Disk Utilities menu.

Note: If you use this backup diskette to restore the current data base after the upgrade, you will have to do a data base conversion after restoring. Refer to Performing a Data Base Conversion, in Section 3.4.5 on page 43. If you do not do the conversion after restoring from this diskette, the data base will not be compatible with the new version of software.

7. Power down the system in accordance with the information appropriate to your system (Section 3.4.2 for V3.3, Section 3.4.3 for V4.0, 4.1, or earlier V4.2 Generics).

3.4.2 Upgrading from Generic V3.3

Whether your switch is redundant or non-redundant, you must power down the switch to allow for the upgrade of the 8Mb CPU firmware and the replacement of NBC cards with NBC3 cards (NBC cards are **not** hot-swappable).

3.4.2.1 VCO-80

Locate the circuit breaker located on the back of the VCO-80 and place it in the down position. **Do Not** power down the power supplies individually. Proceed to Section 3.4.4.

3.4.2.2 SDS-1000

Turn off the two VME power supplies. Proceed to Section 3.4.4.

3.4.2.3 SDS-500

Turn off the VME power supply. Proceed to Section 3.4.4.

3.4.3 Upgrading from Generic V4.0, V4.1, or V4.2 FSR00 through V4.2 FSR00 PUN25

Note: If you are upgrading from V4.2 FSR00 or higher, the CPU firmware on an 8Mb/25MHz CPU does not need to be upgraded.

3.4.3.1 VCO-20

For a VCO-20, locate the circuit breaker located on the back of the VCO-20 and place it in the down position. Proceed to Section 3.4.4.

3.4.3.2 VCO-80

Whether your switch is redundant or non-redundant, you must power down the VME Control Section to allow for the upgrade of the 8Mb CPU firmware.

For a redundant VCO-80, turn off both VME power modules. Power can remain on the port subparts.

For a non-redundant VCO-80, turn off the A-side VME power module. Power can remain on the port subracks.

Proceed to Section 3.4.4.

3.4.3.3 SDS-1000

Whether your switch is redundant or non-redundant, you must power down the VME power supplies to allow for the upgrade of the 8Mb CPU firmware.

For redundant or non-redundant systems, Turn off the two VME power supplies. Proceed to Section 3.4.4.

3.4.3.4 SDS-500

Power down the VME power module. Proceed to Section 3.4.4.

3.4.4 Installing the Software

The following provides instructions for installing Generic V4.2 FSR00 PUN26 on systems currently running V4.0 FSR00 or later and V3.3 FSR00 through V3.3 FSR06. Installation procedures for Ethernet and optional software follow the Generic installation.

Note: Call Summa Four at 1-800-978-6642 (or 603-695-1293) if you are running a Generic other than the above.

On Disk 1, the "Incremental Install Basic System Software" option (option 2) installs the Generic software and downloads files onto the hard disk. This selection does not format the hard drive.

Note: Before continuing, make certain that you have completed your database backup and hardware/firmware replacement.

The instructions in the following subsections assume that the system console is connected to the CPU-TM of the side being installed.

CAUTION: Do not install the MIB - Supplemental Disk software on the switch. The MIB software is installed on the Host computer. Refer to Section 3.6, *Installing the MIB Software*. Do this after completing the installation of the Generic software on the switch.


3.4.4.1 Installing the Generic Software

With the database backed up, the switch powered down (Section 3.4.1), and with the new hardware and firmware in place; install the new Generic software on your system:

1. Insert Disk 1 into the floppy diskette drive (A-side if this is a non-redundant system, B-side if you are returning to this procedure to install software for that side).
2. Connect or switch the administration console to the A-side CPU-TM, or go to the A-side system console.
3. Place the AAC Select Switch in the A position.
4. Power up the A-side.
5. After the system performs diagnostic tests, the Installation Utilities menu appears (*Figure 3.12*).
6. The cursor is located in the Enter Selection data entry field. Type **2**, (for Incremental Install of Basic System Software) then press **Return**.

The following message appears:

Do You Wish To Back-Up The System Data Base? (Y/N) =N?_



TP000122

Figure 3.12: Installation Utilities Menu

7. Press **Return** (this defaults to N).
The database will not be backed up at this time. Make certain that the database was backed up previously, as described in Section 3.4.1 of this installation procedure.
8. The following message appears:

Insert disk 2 of Installation Set
Press return to continue

Remove the current diskette from the drive, insert Disk 2, and press **Return**. The system copies the files from Disk 2 to the C: drive in the /BOOT, /DBASE, /LOG and /TRACE directories.
9. When all the files from Disk 2 are copied, the following message appears:

Insert disk 3 of Installation Set
Press return to continue

Remove the current diskette from the drive, insert Disk 3 then press **Return**. The system copies the files from Disk 3 onto the C: drive.
10. This pattern, of the system copying from the diskette then prompting for the next, continues until all five diskettes have been loaded and copied onto the system. Continue to remove and insert the installation diskettes when prompted to do so.

When the installation is complete, the Installation Utilities menu appears again (*Figure 3.12*).
11. Optional software needs to be installed every time you update the Generic to ensure NVRAM update. For options such as TeleRouter, ISDN-NFAS, or Ethernet, type **4**, Install Another Software Option, then press **Return**.

The following message appears:

Insert Another Install Disk

Press Return To Continue

Instructions for installing Ethernet for the Host and SNMP communications are contained in the next section, Section 3.4.4.2.

NOTE: When you install a software option (such as TeleRouter, etc.) on a system, the installation process makes changes to the nonvolatile RAM (NVRAM) on the CPU. These changes make operation of software options specific to the CPU on which you installed the options. For this reason:

- *Software options must be installed on both system controllers in a redundant system.*
- *Software options must be reinstalled if the CPU is replaced. Although the data base information resides on the hard disk, a new CPU is unable to access this information.*

Because of the reliability of the CPU, failures requiring replacement are very rare occurrences.

If you are installing Ethernet, go to that section now. If you have other optional software to install after you have installed the Generic, see Section 3.4.4.3 for generalized installation instructions. More information on optional software installation is provided in the appropriate product supplement.

- a. If there is no Ethernet or optional software to be installed, continue to Section 3.4.5 to convert your database.


3.4.4.2 Installing Ethernet for Host and SNMP Communication and Configuring NFS

You can install Ethernet software as part of the generic software installation or separately. For complete installation instructions, refer to the supplement provided with the Ethernet software.

The following section provides generalized instructions for installing Ethernet optional software package. It is assumed that this step is being completed as part of the overall install and is being done as a continuation of *Installing the Software*.

To install and configure the Ethernet optional software, follow these steps:

1. Insert the Ethernet software diskette and press the **Return** key. After the system loads the Ethernet files from the diskette, the Ethernet Installation Utilities menu appears with the cursor located in the Enter Selection field (see Figure 3.13).



TP000122

Figure 3.13: Ethernet Installation Utilities Menu

2. To install and configure the Ethernet software, type **1** and press **Return**. The following message appears:

Do You Wish To Back-Up The System Data Base? (Y/N) =N?_

Press **Return** (this defaults to N). You will not be backing up the data base at this time. Data base backup should have been done in Section 3.4.1 of this installation.

The Ethernet Configuration menu appears (see *Figure 3.14*).

```

                                E T H E R N E T   C O N F I G U R A T I O N

1) Install Ethernet Options
2) Edit Ethernet Parameters
3) Edit SNMP Management Station Parameters
4) Edit NFS Parameters
5) Edit Gateway Routing Table Parameters
6) Exit Ethernet Configuration

Enter Selection: __

```

TP000019

Figure 3.14: Ethernet Configuration Menu

3. Type **1** and press **Return**. The following message appears:

```
Copy A:/BOOT/ETHERNET.EXE
1 files(s) copied
Ethernet Option Enabled
```

4. To set the Ethernet Parameters, type **2** and press **Return**. The following message appears:

```
System Internet Address = 107.3.254.98?
```

Note: The Ethernet and Internet address numbers that you see in the screen messages in this section are only examples. In your system these numbers are replaced by numbers that represent your system addresses.

5. Set the Internet Address of this system and press **Return**.

```
Set System Internet Address To 107.3.254.98 (Y/N) =Y?
```

6. If you change the address, you are prompted to confirm your new address. Type **Y** to confirm your selections. The following confirmation message appears:

```
System Internet Address Configured
```

7. Set the System Subnet Mask, or press **Return** to accept the displayed value.

After you complete this step, you can connect a remote console to your system via Telnet.

8. a. If you are *not* going to manage this system with SNMP, go to Step 14.
b. If you *are* going to manage this system with SNMP, type **3** and press **Return** to set the SNMP Management Station Internet address. The following message appears:

SNMP Management Internet Address = 0.0.0.0?

9. Set the Internet address to the address of the system that you are using as the NMS (Network Management System). Press **Return**. The following message appears:

Set SNMP Management Internet Station Address To 189.7.107.44 (Y/N) =Y?

10. Type **Y** to confirm your selections. The following confirmation message appears:

SNMP Management Station Internet Address Configured

After you complete this step, the system will report SNMP trap messages to the NMS that you selected.

11. a. If you are not going to boot your system over the network, go to Step 14.
b. If you are going to boot your system over the network, continue with Step 12.

12. Type **4** to set the Network File System (NFS) server parameters. The following selections appear one at a time. Enter the information for your system. Type **Y** and press **Return** after each selection.

Enable NFS Access (Y/N) =Y?

NFS Server Internet Address = 000.0.000.000?

NFS Server Name =xxx?

NFS Mount Directory Point #?

Target System Name =

Target System User Id =

Target System Group Id =

Target System Umask =

Update NFS Configuration With Above Data (Y/N) =Y?

13. After you update the NFS configuration with the new data, the following message appears:

NFS Configuration Updated

You can now save the log files and database to a remote location.

14. Type **6** to exit the Ethernet installation. The Installation Utilities screen appears (see Figure 3.13).

15. Remove the Ethernet diskette from drive A.

16. If you have additional optional software to install, proceed to Section 3.4.4.3, *Installing Optional Software*, which follows.

17. If there is no optional software to install, proceed to Section 3.4.5, *Performing a Data Base Conversion*.

3.4.4.3 Installing Optional Software


You can install optional software as part of the generic software installation or separately. For complete installation instructions, refer to the supplement provided with the optional software.

The following section provides generalized instructions for installing an optional software package. It is assumed that this step is being completed as part of the overall install and is being done as a continuation of *Installing the Software*.

To install optional software, follow these steps:

1. Insert the optional software diskette, type **4**, and press the **Return** key.

If you are installing optional software such as TeleRouter or ISDN-NFAS, the name of the optional software being installed appears in place of *Ethernet* in choices 1 and 2 (*Figure 3.15*).



TP000122

Figure 3.15: Optional Software Installation Utilities Menu

2. To install and configure the optional software, type **1** and press **Return**. The following message appears:

Do You Wish To Back-Up The System Data Base? (Y/N) =N?_

Press **Return** (this defaults to N). You will not be backing up the data base at this time. Data base backup should have been done in Section 3.4.1 of this installation.

3. The following messages appears for most options:

Copying A:/Option Filename.EXE...

n file(s) copied

Option Name Option Enabled

4. If you are installing additional software packages, press **4**, (Install Another Software Option) and repeat the steps above.
5. After you install the last optional software package, proceed to Section 3.4.5.

3.4.5 Performing a Data Base Conversion

Since the data base tables have changed, it is mandatory that you do a data base conversion. To do this, select option **5** in the Installation Utilities menu and press **Return**.

The conversion takes a few seconds. The following message is displayed on the screen:

Data base path for conversion: C:/dbase/

If the database does not need to be converted (i.e. it had previously been converted), no other messages are displayed. However, if you do convert the database, several other messages may be displayed. For example:

Converting the System Configuration table ...

This will take just a few seconds.

If you are upgrading a non-redundant system or you have finished installing software on the B-side of a redundant system, the upgrade is complete after you perform the database conversion on both sides of the switch. Type **7**, Terminate Installation (refer to *Figure 3.15*), and press **Return**. The system will prompt with "Terminate?". Enter **Y** and press **Return**.

If you are upgrading a redundant system, you can boot the A-side of the system (the side you have just completed upgrading) at this time to process calls. This is optional and can be done later, after you upgrade the B-side. Continue to the next section to complete the upgrade by installing software on the B-side.

3.4.6 Installing the Software on the B-Side

If you do not have a redundant system, proceed to Section 3.5, *Upgrading to the 16Mb/33MHz CPU*, if you have a Network Management System.

1. Connect or switch the administration console to the B-side CPU-TM, or go to the B-side system console.
2. Insert Disk 1 into the B-side drive.
3. Power on the B-side.
4. After the system performs diagnostic tests, repeat *Section 3.4.4, Installing the Software*, starting with Step 5 on page 8, to install the Generic software and optional software, and then Section 3.4.5, *Performing a Data Base Conversion*, on the B-side.

5. After you have installed the software and converted the database on the B-side, type **7, Terminate Installation** (refer to *Figure 3.15*), and place the ACC switch back into the Auto position. The B-side will reboot itself. Proceed to the next section to verify file synchronization.

3.4.7 Verifying File Synchronization

For redundant systems, after you have installed the software on both sides and rebooted the system, you must verify that file synchronization has occurred. Check the messages in the log file and verify that:

```
RED32:ACT FILE SYNC COMPLETED
```

from the ACT side, and

```
RED20:SBY FILE SYNC COMPLETED
```

from the SBY side, appear.

When file synchronization has been verified, the installation of system software is complete. Proceed to the next section to install the MIB software if you have a Network Management System.

3.5 UPGRADING TO THE 16MB/33MHZ CPU

If you are swapping out your 8Mb/25MHz CPUs with 16Mb/33MHz CPUs, do so now. See the CPU Upgrade Procedure, Version 4.2 FSR00 PUN24 and higher, P/N 63104050100.

3.6 INSTALLING THE MIB SOFTWARE

If you use SNMP to manage your switch, install the MIB software on your network management system. See Appendix C in the V4.2 FSR00 Release Notes.

This completes your upgrade to Generic V4.2.

Section 4

KNOWN DESIGN CONSTRAINTS

4.1 INTRODUCTION

Note: No new design constraints have been introduced with the V4.2 FSR00 PUN 22, 23, 24, 25, or 26 releases.

Summa Four, Inc. has identified and evaluated design constraints in Generic V4.2 FSR00 software, firmware, and hardware. This section provides explanations of, and where applicable, workarounds for, design constraints in the following areas:

- Upgrading to V4.2 on SDS and VCO/80 Systems
- Simple Network Management Protocol (SNMP)
- System Configuration Utilities
- Systems Considerations
- Software Exceptions on System Controller
- Card Initialization
- DTG-2 Card Alarms
- T1 Trunk Card Support
- Digit Collection
- Inpulse Rule Processing
- Resource Group Processing
- Conferencing
- MVDC-T1
- Operational Constraints
- Connecting to Modems
- IP Addressing

Section 5

KNOWN FUNCTIONAL CONSTRAINTS

5.1 INTRODUCTION

Summa Four, Inc. has identified and evaluated functional constraints in Generic V4.2 FSR00 PUN26 software, firmware, and hardware.

This section provides explanations and, where applicable, workarounds for functional constraints for each PUN release in the following areas:

- System Administration
- System Configuration Utilities
- Special Redundant Systems Considerations
- Disk Operations
- Digit Collection
- Inpulse/Outpulse Rule Processing
- Call Processing
- Command/Report Processing
- Initialization
- Network Bus Controller-3 (NBC-3)
- Digital Tone Generator (DTG) and Digital Tone Generator-2 (DTG-2)
- Four Span Cards
- Miscellaneous Card Issues
- Multiple Host Connections
- TeleRouter
- Simple Network Management Protocol (SNMP)
- Ethernet
- ISDN Issues
- International Issues

5.2 SYSTEM ADMINISTRATION

Not all system administration tasks are supported by SNMP. (See the V4.2 FSR00 release notes for a list of the tasks not supported.) There is no SNMP support for Network Side NET5, the REORDER tone feature for Japanese networks, or for other V4.2 FSR00 PUN 22 to PUN 26 features.

5.2.1 U508295234/TR5234: Adding Cards to End of Configured Data Base

If you try to add cards to the end of a configured data base, you may see the following message: NO AVAILABLE PORT MEMORY. This is caused by port fragmentation, which means that there are enough total ports, but they are not contiguous.

This could happen, for example, if 1576 ports are assigned out of the 1776 that were licensed, and you try to add a 64-port IPRC.

Resolution

Rebuild the data base to reallocate the ports in a contiguous block.

5.3 DISK OPERATIONS

5.3.1 U805280001: System Crashes when Reading a Floppy

Floppy disks formatted successfully on the switch may subsequently produce an error when a directory display is attempted or may cause a core dump and system reboot when a read is attempted.

This occurs only when the floppy is formatted with a volume label containing an illegal character is included in the file name. Illegal characters include the following:

*?/\ | ,; : + = [] { } & ^ < > ”.

Resolution

Change the volume label with Microsoft Windows or other external tools capable of writing MS-DOS format on floppies.

5.4 NETWORK BUS CONTROLLER-3 (NBC-3)

5.4.1 U803230005: NBC-3 Crashes when MSC Reboots

When an MSC connected to a switch via a T1 or 4XT1 card is rebooted the NBC-3 (and the switch on that side) will crash.

5.5 FOUR SPAN CARDS

5.5.1 U507185123: Processing WINK Command

Note: This was erroneously listed under the following number in the V4.2 FSR00 release notes: U507201007.

When the Four Span T1 is configured as FXO-LX, the card processes a WINK command after it seizes out. The card does not support a WINK, but will accept the command without an error; there is no indication that the customer's inpulse/outpulse rule is invalid.

Resolution

Do not use a WINK in an Outpulse rule when Four Span T1 cards are configured as FXO-LX.

5.5.2 U710290005: MVDC T1 Fails to Clear Alarms

When multiple MVDC T1 cards are installed in a subrack, some cards re-download after a warm restart. The cards finally clear alarms after the download is complete. Also, there are queue overflows with data lost on RED_TX_Q, SCR_MSG_Q, CP_TX_Q, and SNMP_MSG_Q.

5.5.3 U710300008: Aborted Download Does Not Resume After Switchover

In a redundant system, when a download is in progress and an Active to Standby switchover occurs, the MVDC download aborts on the previously Active side but does not resume on the new Active side.

5.5.4 U710310001: Display Card Data Screen Not Recording Slips

The Display Card Data screen does not record slips. The system was forced to slip by changing the AM2-D bulk call generator from internal to LINE A. Slips are recorded at the load box but the slip count does not increase on the Display Card Data screen.

5.6 MISCELLANEOUS CARD ISSUES

5.6.1 U609230005: Outgoing T1 Stuck in CP_OUTPUL

Outgoing ports on Single Span T1 cards intermittently became stuck in CP_OUTPUL after incoming seizures.

Appendix A

Replacing PROMs and PLDs

A.1 INTRODUCTION

This appendix describes the procedures for installing new firmware and programmable logic in circuit cards. Firmware is shipped in the form of programmable read only memory (PROMs), dual in-line packages (DIPs), integrated circuits (ICs) for through-hole mounting, and plastic leaded chip carriers (PLCC) for surface mount.

Programmable logic is shipped in the form of programmable logic devices (PLDs), DIPs for through-hole mounting, and PLCCs for surface mount.

PROMs are labelled with configuration data which should be checked, prior to installation, against the firmware requirements contained in *Section 2*. PLDs are labelled with their LP identification number.

A.2 REMOVING AND REPLACING THROUGH-HOLE PROMs and PLDs

The following sections provide information about removing and replacing through-hole PROMs and PLDs. Refer to the appropriate technical description for the physical locations of the PROMs and PLDs on each circuit card.

A.2.1 Removing Through-Hole PROMs and PLDs

To remove a through-hole PROM or PLD, follow these steps.

1. If the circuit card is currently installed in the system, follow the removal and replacement procedures in the appropriate technical description. Be sure to also locate affected circuit cards kept as spares.

CAUTION: Observe antistatic precautions near circuit cards. Wear a ground strap connected to the equipment frame whenever servicing or cleaning circuit cards (ground points are indicated by labels on the system front).

2. Remove the PROM to be replaced from the circuit card. Use a PROM removal tool to grasp the integrated circuit and pull it straight up and away from the socket.

CAUTION: Avoid using devices, such as screwdrivers, to remove PROMs. These devices can damage PROM pins and scratch the circuit card.

3. Remove the PROM chip from the shipping package. Refer to *Section 2* to verify that the label on the chip matches the software requirements.

A.2.2 Replacing Through-Hole PROMs and PLDs

To replace a through-hole PROM or PLD, follow these steps.

1. Before installing the new chip, verify that its pins are all evenly spaced and vertically aligned. If necessary, align the IC pins properly prior to installation. To align the pins, you can either use a commercially available pin-straightener tool, sized for a 28-pin DIP device, or you can lay the PROM or PLD on its side and gently press the top edge, being careful not to press on the pins (Figure A.1). Repeat this procedure for the other row of pins.




Figure A.1: Aligning PROM or PLD Pins

2. Orient the PROM or PLD chip so that the notch in the chip (Figure A.2) faces the notch on the circuit card.




Figure A.2: Notch Orientation for Integrated Circuit

3. Carefully insert the pins on one side of the PROM or PLD chip into holes on the correct side of the socket (see Figure A.3).




Figure A.3: Inserting Pins in One Side of Socket

4. Insert the pins on the other side of the PROM or PLD chip into holes on that side of the socket (see Figure A.4).




Figure A.4: Inserting Pins in Other Side of Socket

NOTE: If the pins are not aligned with the socket holes, remove the PROM or PLD chip and straighten the pins (see Step 1). After realigning the pins, repeat Step 2 through Step 4.

5. Carefully examine all the pins on the PROM or PLD chip. Be sure that none of the pins are bent or touching one another.
6. With all of the pins inserted into the socket holes, apply gentle and even pressure to the top of the chip until it is fully seated in the socket.
7. Re-install the circuit card in the system or return the card to spares stock.

A.3 REMOVING AND REPLACING SURFACE-MOUNT PROMs and PLDs

The following sections provide information about removing and replacing surface-mount PROMs and PLDs. Refer to the appropriate technical description for the physical locations of the PROMs and PLDs on each circuit card.

CAUTION: Make sure you use the proper tool to remove surface mount PROMs and PLDs, or you may damage the board.

A.3.1 Removing Surface-Mount PROMs and PLDs

To remove a surface-mount PROM or PLD, follow these steps.

1. If the circuit card is currently installed in the system, follow the removal and replacement procedures contained in the appropriate technical description. Be sure to also locate affected circuit cards kept as spares.

CAUTION: Observe antistatic precautions near circuit cards. Wear a ground strap connected to the equipment frame whenever servicing or cleaning circuit cards (ground points are indicated by labels on the system front).

2. Use the surface-mount chip removal tool, provided by Summa Four, Inc. to remove the PROM or PLD that is to be replaced on the circuit card. To remove the PROM or PLD chip:
 - a. Spread or compress the tool legs so the tongs fit into the slots of the chip carrier socket.

- b. Insert the tool tongs into the slots of the socket, and push firmly so that the tool butts on the socket.
 - c. Place the thumb and forefinger on the tool's grip. Squeeze the thumb and forefinger together to remove the chip from the socket.
3. Remove the PROM or PLD chip from the shipping package. Refer to *Section 2* to verify that the label on the chip matches the software requirements.

A.3.2 Replacing Surface-Mount PROMs and PLDs

To replace a surface-mount PROM or PLD, follow these steps.

1. Before installing the new PLD, verify that the pins are all evenly spaced and properly aligned. If necessary, use tweezers to carefully align the IC pins prior to installation.
2. Align the notch or chamfered edge on the PLD to the silkscreened dot on the circuit card (see Figure A.5).




Figure A.5: PLD Alignment

3. With all pins aligned to the pins of the socket, apply gentle, even finger pressure to the top of the chip until it is fully seated in its socket. This completes the installation of the surface mount chip.
4. Reinstall the circuit card in the system or return the card to spares stock.

Appendix B

Live Upgrade Messages

B.1 INTRODUCTION

This appendix describes the Prompts, Warnings, and Error messages associated with the live upgrade feature.

B.1.1 Prepare for Install Messages

The following is a list of messages that may be displayed during the Prepare for Install step of the Live Upgrade process.

Creating Directory Structure on Device C:

This indicates that the temporary directory structure required for the upgrade is being created.

Directory Structure Created

This indicates that the temporary directory structure has been created.

BOOT and DBASE Files Saved

This indicates that the files from the /BOOT and /DBASE directories have been copied to the temporary directories. The files are maintained there during the upgrade in case it is necessary to abort the upgrade and restore the original software.

B.1.2 Installing New Software Messages

The following is a list of messages that may be displayed during the Installing New Software step of the Live Upgrade process.

Installing from Generic Diskette #

This indicates that the files from the specified diskette are being installed.

Copying File *filename*

This indicates that a specific file is being copied to the hard disk.

File not found *filename*

This indicates that the generic software expected a file to be present on the diskette during the install process. Instead, the file was not found. An abort of the upgrade will follow.

Note: This message may appear if there is insufficient space on the hard disk.

All Files from Floppy Copied

This indicates that all files were successfully copied from the diskette.

Installing from *optional software* Diskette

This indicates that the files from the optional software diskette are being installed.

Copying Optional Software Failed

This indicates that the installation of the optional software package failed.

Invalid Optional Software Floppy

This indicates that the diskette does not represent a valid software option.

B.1.3 Prepare for Upgrade Messages

The following is a list of messages that may be displayed during the Prepare for Upgrade step of the Live Upgrade process. An index of critical upgrade information (CUI) is generated during the Prepare for Upgrade step and recorded in the upgrade log. The critical upgrade information messages are described below.

All Files Present

This indicates that the check of required files was successful.

Check For All Files FAILED

This indicates that the check of required files failed. An abort of the upgrade process will follow.

Copying New Files

This indicates that the newly installed software is being copied from the temporary directories into the system /BOOT and /DBASE directories.

Copied New Files

This indicates that the copy of the newly installed software to the system /BOOT and /DBASE directories is complete.

Getting Single Resource Information

This indicates that the generic is reviewing the current database configuration for information which may impact uninterrupted service provided by single resources.

Existing Version of *filename.tbl* is a.b.c. New Version is x.y.z.

This indicates that the existing version of the specified database table is later than the newly installed version. This does not represent a valid upgrade. An abort of the upgrade will follow.

Cannot Upgrade to Lower Version. Aborting

This indicates that the administrator has installed a version of software which is earlier than the existing software. This does not represent a valid upgrade. An abort of the upgrade will follow.

CUI#: Firmware Incompatible, Upgrade Required for *cardtype* at X,X,XX

This indicates that the firmware presently installed on the specified card is not compatible with the newly installed software. It will be necessary for the administrator to upgrade the firmware during the Card Cutover step. The administrator should verify that the current version of firmware is available and that the loss of this resource during cutover will not impact service significantly.

CUI#: Firmware Compatible, Upgrade Recommended for *cardtype* at X,X,XX

This indicates that the firmware presently installed on the specified card is compatible with the newly installed software, though it is not the current version. It is recommended that the administrator upgrade the firmware during the Card Cutover step. The administrator should verify that the current version of firmware is available and that the loss of this resource during cutover will not impact service significantly.

CUI#: Redundant BRC pair does not exist, active pair requires upgrade!!

This indicates that the BRC requires an upgrade and a redundant BRC pair does not exist in the database. The process of upgrading the BRC pair will result in the loss of all resources in the subrack supported by the BRC pair. The administrator should verify that the loss of this subrack during cutover will not impact service significantly.

CUI#: *cardtype* at X,X,XX is the Last/Only Active Card of Resource Group #

CUI#: *cardtype* at X,X,XX, Limbo Card of NFAS Group # Requires Upgrade

CUI#: *cardtype* at X,X,XX, Last Resource of B Chnls of NFAS Group # for Upgrade

These messages indicate that the specified card types require upgrade, though the loss of these resources impact the groups with which they are associated.

CUI#: NBC3/DTG2 at X,X,XX Upgrade Required During Update Generic Step

This indicates that the NBC3/DTG2 upgrade(s) required cannot be done during the Card Cutover step. These cards must be upgraded during the Update Generic step of the Live Upgrade process.

CUI#: Critical Upgrade Information Present in Upgrade Log

This indicates that one or more critical upgrade information messages appear in the upgrade log. The administrator should review these before continuing with the upgrade.

B.1.4 Enable/Disable/Configure Optional Software Messages

The following is a list of messages that may be displayed when in the Enable/Disable/Configure Optional Software screen.

Optional Software Not Installed

This indicates that no software options were installed. There is nothing to enable, disable, or configure.

Optional Software Configure, Complete

This indicates that the configuration of software options is complete. This message is generated when the administrator leaves the Enable/Disable/Configure Optional Software screen.

SOFTWARE OPTION Enabled

This indicates that the specified software option was enabled in the Enable/Disable/Configure Optional Software screen. This message is also printed in the upgrade log to provide a record of the configuration of the software option.

SOFTWARE OPTION Disabled

This indicates that the specified software option was disabled in the Enable/Disable/Configure Optional Software screen. This message is also printed in the upgrade log to provide a record of the configuration of the software option.

ENTER To Confirm Disable

This prompts the user to confirm that the software option should be disabled.

Note: If accessing the switch via Ethernet, disabling the Ethernet optional software will prevent you from accessing the switch after the Update Generic step.

B.1.5 Card Cut-Over Messages

The following is a list of messages that may be displayed when in the Card Cut-Over screen.

Invalid Operation. Must be (A, G, or F)

The user enter an invalid option. Only A, G or F can be entered in the command field.

Card Does Not Require Upgrade

This message is displayed if the user entered a card location other than one from the list. Re-enter a card location from the displayed list, in accordance with the system convention for identifying rack, level, slot, and interface.

RLSI X,X,XX Being Forced OOS

This message appears after the user has entered the F command to force the card OOS. The system forces the card specified by the rack, level, slot and interface, out-of-service (OOS).

RLSI X,X,XX Being Gracefully Idled

This indicates that the user has entered the G command to gracefully idle the card. The system gracefully takes the card specified by the rack, level, slot and interface, out-of-service (OOS).

RLSI X,X,XX Is Now OOS

This indicates that the card, indicated by rack, level, slot and interface has become out-of-service (OOS).

RLSI X,X,XX Is Now Active

This indicates that the card indicated by rack, level, slot and interface has become active.

Taking Active BRC OOS, Continue?

This warns the user that a BRC card to be taken out-of-service (OOS), will cause a BRC switchover. The user can press the Enter key to continue or any other key to abort.

Last Active Card of ResGrp #! Continue?

Limbo Card of NFAS Group #!, Continue?

Last B chnls of NFAS Grp #!, Continue?

The user is taking the last card of the specified group out-of-service (OOS) as the result of a G or F command. The user can press the Enter key to continue or any other key to abort.

Active DTG, Will Lose Tones! Continue?

The user is taking the active DTG card out-of-service (OOS) as the result of a G or F command. If a standby DTG/DTG-2 is present, a DTG switchover will occur. Otherwise, the switch will be without tone generation and outpulsing during the DTG upgrade. The user can press the Enter key to continue or any other key to abort.

Note: This applies only to DTG cards. This does not apply to DTG-2 cards.

Card Already OOS

The user tried to change the status of the card to OOS when the card was already out-of-service (OOS).

Not Allowed!! Card Gracefully Idling

The user tried to change the status of the card to OOS when the card was gracefully idling.

NBC3/DTG2 Cutover Not Allowed

The user selected an NBC3/DTG2 card for cutover. The NBC3/DTG2 card upgrade must be performed during the Update Generic step.

No Cards Require Cutover

This user selected the Card Cutover screen, however no cards require cutover.

B.1.6 General Live Upgrade Messages

The following is a list of messages that may be displayed during the Live Upgrade process.

Invalid Option

The user selected an option from the Live Upgrade Control Menu which is not valid.

Live Upgrade Aborting...

The Live Upgrade process has initiated an abort sequence. The abort sequence is initiated by the user or initiated automatically when a configuration issue has been identified.

Restored Original C:/BOOT and C:/DBASE files

This indicates that the original /BOOT and /DBASE files have been restored from the temporary directories as part of the abort sequence.

Live Upgrade Aborted...

This indicates that the abort sequence has completed.

Operation Not Allowed During Upgrade,

This indicates that the requested operation cannot be performed while the switch is undergoing a live upgrade.

Waiting for Stable State

This indicates that the switch is preparing itself for a reset of the standby controller. Upon reboot of this controller, the newly installed generic software will be running.

Resetting System ...

This indicates that switch has prepared itself for the reset of the standby controller and the reboot will follow shortly.

Switchover Not Allowed During Upgrade, (maint menu switchover)

The user has requested a manual switchover from the Maintenance Menu during a live upgrade. This is not allowed during the live upgrade process.

