



Doc. No. 78-4669-03

Installing Interface Boards in the Cisco LocalDirector

The instructions in this document describe how to remove the Cisco LocalDirector access panel and install an upgrade or spare interface. For configuration information, refer to the *Cisco LocalDirector Installation and Configuration Guide* supplied in the accessory kit with your unit.

Note Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM, a member of the Cisco Connection Family, is updated monthly. Therefore, it might be more up to date than printed documentation. To order additional copies of the Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www-europe.cisco.com>.

This guide contains the following topics:

- “Safety Warnings,” page 1
- “Supported Interfaces,” page 3
- “Removing and Replacing Interface Boards,” page 5
- “Cisco Connection Online,” page 9

Safety Warnings



Warning Means *danger*. You are in a situation that could cause bodily injury. Before you work on any equipment, you must be aware of the hazards involved with electrical circuitry and familiar with standard practices for preventing accidents. To see translations of the warnings that appear in this document, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

Waarschuwing Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van

Corporate Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA

Copyright © 1997
Cisco Systems, Inc.
All rights reserved.

standaard maatregelen om ongelukken te voorkomen. Voor vertalingen van de waarschuwingen die in deze publicatie verschijnen, kunt u het document *Regulatory Compliance and Safety Information* (Informatie over naleving van veiligheids- en andere voorschriften) raadplegen dat bij dit toestel is ingesloten.

Varoitus Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä varoista ja tavanomaisista onnettomuuksien ehkäisykeinoista. Tässä julkaisussa esiintyvien varoitusten käänökset löydät laitteen mukana olevasta *Regulatory Compliance and Safety Information* -kirjasesta (määräysten noudattaminen ja tietoa turvallisuudesta).

Attention Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant causer des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions d'avertissements figurant dans cette publication, consultez le document *Regulatory Compliance and Safety Information* (Conformité aux règlements et consignes de sécurité) qui accompagne cet appareil.

Warnung Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewußt. Übersetzungen der in dieser Veröffentlichung enthaltenen Warnhinweise finden Sie im Dokument *Regulatory Compliance and Safety Information* (Informationen zu behördlichen Vorschriften und Sicherheit), das zusammen mit diesem Gerät geliefert wurde.

Avvertenza Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti. La traduzione delle avvertenze riportate in questa pubblicazione si trova nel documento *Regulatory Compliance and Safety Information* (Conformità alle norme e informazioni sulla sicurezza) che accompagna questo dispositivo.

Advarsel Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskade. Før du utfører arbeid på utstyr, må du vare oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker. Hvis du vil se oversettelser av de advarslene som finnes i denne publikasjonen, kan du se i dokumentet *Regulatory Compliance and Safety Information* (Overholdelse av forskrifter og sikkerhetsinformasjon) som ble levert med denne enheten.

Aviso Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes. Para ver as traduções dos avisos que constam desta publicação, consulte o documento *Regulatory Compliance and Safety Information* (Informação de Segurança e Disposições Reguladoras) que acompanha este dispositivo.

¡Advertencia! Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes. Para ver una traducción de las advertencias que aparecen en esta publicación, consultar el documento titulado *Regulatory Compliance and Safety Information* (Información sobre seguridad y conformidad con las disposiciones reglamentarias) que se acompaña con este dispositivo.

Warning! Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador. Se förklaringar av de varningar som förkommer i denna publikation i dokumentet *Regulatory Compliance and Safety Information* (Efterättelse av föreskrifter och säkerhetsinformation), vilket medföljer denna anordning.



Warning Before working on a system that has an on/off switch, turn OFF the power and unplug the power cord.



Warning Do not work on the system or connect or disconnect cables during periods of lightning activity.



Warning Do not touch the power supply when the power cord is connected. For systems with a power switch, line voltages are present within the power supply even when the power switch is off and the power cord is connected. For systems without a power switch, line voltages are present within the power supply when the power cord is connected.



Warning Before working on equipment that is connected to power lines, remove jewelry (including rings, necklaces, and watches). Metal objects will heat up when connected to power and ground and can cause serious burns or weld the metal object to the terminals.

Supported Interfaces

Table 1 shows the interfaces that are supported on the LocalDirector platforms:

Table 1 Supported Interfaces by Platform

	4-Port Ethernet	10/100 Ethernet	FDDI
LocalDirector 420	1 supported in version 1.6.5, up to 4 in version 2.x	not supported	2 supported
LocalDirector 415 (original platform, CA-LDIR)	1 supported in version 2.x	2 supported in version 1.6.5, 3 supported in version 2.x	2 supported
LocalDirector 410	not supported	2 supported in version 1.6.5, 3 supported in version 2.x	not supported

Interface Numbering

The LocalDirector interface numbering scheme will change with the introduction of 4-port Ethernet cards. The 4-port interfaces on the LocalDirector 420 are numbered left to right, top to bottom, and the three 10/100 interfaces on the LocalDirector 410 are read left to right.


Interfaces on the LocalDirector 415 are numbered right to left, bottom to top. Interface numbering on existing LocalDirector 415 units will remain the same in version 1.6.x, but will change to left to right, top to bottom in version 2.x.

Note Interface numbering on the LocalDirector 415 will remain the same in version 1.6.x, but will reverse when upgraded to version 2.x.

FDDI Interfaces

FDDI interface boards for the LocalDirector have dual-attached SC connectors. When installed in the LocalDirector, port A is on the bottom of the interface, and port B is on the top as shown in Figure 1:

Figure 1 LocalDirector FDDI Interfaces



4-Port Ethernet Interfaces

4-port Ethernet cards are supported on the LocalDirector 420, and the LocalDirector 415 will support 4-port Ethernet in version 2.x. The LocalDirector 410 does not support 4-port Ethernet cards.

LEDs

Each interface port has two LEDs, one amber and one green. Table 2 explains the states of the LEDs on the 4-Port interface cards.

- Green - Indicates data transmission activities relative to the amount of traffic.
- Flashing amber - Autosensing in progress (even with no configuration and no cable connections).
- Steady amber - Active connection (this is normal operation).
- The **interface ethernet 0 auto** command causes the amber LED to blink continually when the link is not up, and **interface ethernet 0 [10baset|100basetx|100full]** shuts off the amber LED when the link is not up.

Table 2 4-Port Interface LEDs

LED	LED State	Indication
Green	off	No data transmission.
	on	Steady data transmission.
	flashing	Intermittent data transmission.
Amber	off	Disabled or unused. If the interface was configured with the 10baset , 100basetx , or 100full options, the link is not up yet.
	on	The connection is active.
	flashing	Autosensing. If the interface was configured with the auto option, the link is not up yet.

Note The LED behavior on the 4-port Ethernet interface is different from other Cisco products. Use this information to determine if the LED activity indicates normal interface operation.

Autonegotiation

The 4-port card in the LocalDirector does not autonegotiate. When a 4-port interface is configured using the **int eth 1 auto** command, it will perform autosense. The main difference between autosense and autonegotiation is that autosense can not be used to establish full-duplex links. Use the **int eth 1 100full** command to set full-duplex mode.

Note The 4-port interface will not “autosense” to full duplex. This will cause a problem if the LocalDirector interface is at half duplex and is connected to a switch on the other end trying to do full duplex.

Removing and Replacing Interface Boards

To remove and replace an interface board in a LocalDirector:


- Power-off the unit and remove power cord and cabling
- Open the unit
- Remove or replace the interface board
- Close the unit
- Connect the power cord and cabling, and boot up the unit

LocalDirector 415 (original CA-LDIR)

Take the following steps to remove and replace interface boards in a LocalDirector 415:

- Step 1** Read the *Regulatory Compliance and Safety Information for the Cisco LocalDirector* for important safety information.
- Step 2** Save the existing configuration to flash memory.
- Step 3** Open the front access panel and power-off the unit as shown in Figure 2:


Figure 2 Opening the Front Panel Provides Access to the Power Switch



Removing and Replacing Interface Boards


- Step 4** At the back of the LocalDirector unit, remove the power cord. If you are replacing a board, remove any cabling related to it.
- Step 5** Remove the unit from the equipment rack and place on a stable work surface.
- Step 6** Detach the top access panel by using a Phillips-head screwdriver to remove the 16 screws securing the top panel (12 on top and 4 on the back cover flange) as shown in Figure 3:

Figure 3 Detaching the Access Panel



- Step 7** Remove the top access panel.
- Step 8** If you are replacing an existing circuit board, remove the screw that secures the board to the back of the chassis for each board you are replacing as shown in Figure 4:


Figure 4 Removing an Interface Board



- Step 9** If you are replacing an existing board, remove each board and set it aside.
- Step 10** Remove the new circuit board from its package.

Step 11 Insert each new board in the appropriate slot so that the mounting bracket faces the back of the unit as shown in Figure 5:

Figure 5 Insert the New Interface Board Into the Chassis



Step 12 Attach the screw to the mounting bracket, and replace the top access panel.

Step 13 Put the unit back on the equipment rack and plug in the cables and the power cord.

Step 14 Power-on the unit from the front access panel.

LocalDirector 420 or LocalDirector 410

Take the following steps to remove and replace interface boards in a LocalDirector 420/410:


Step 1 Read the *Regulatory Compliance and Safety Information for the Cisco LocalDirector* for important safety information.

Step 2 Save the existing configuration to flash memory.

Step 3 Power-off the unit from the back panel.

Step 4 Remove the three screws from the top panel at the front of the unit, as shown in Figure 6:


Figure 6 Opening the LocalDirector 420/410 Chassis



Removing and Replacing Interface Boards


Step 5 Slide the lid toward the back of the cabinet, and then lift the lid straight up, as shown in Figure 7:

Figure 7 Detaching the Access Panel



Step 6 If you are replacing an existing circuit board, remove the screw that secures the board to the back of the chassis for each board you are replacing as shown in Figure 8:

Figure 8 Removing an Interface Board




Step 7 If you are replacing an existing board, remove each board and set it aside.

Step 8 Remove the new circuit board from its package.

Step 9 Insert each new board in the appropriate slot so that the mounting bracket faces the back of the unit as shown in Figure 9:

Figure 9 Insert the New Interface Board Into the Chassis



Step 10 Attach the screw to the mounting bracket, and replace the top access panel.

Step 11 Put the unit back on the equipment rack and plug in the cables and the power cord.

Step 12 Power-on the unit from the switch at the back of the unit.

Cisco Connection Online

Cisco Connection Online (CCO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional content and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously: a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>.
- WWW: <http://www-europe.cisco.com>.
- WWW: <http://www-china.cisco.com>.
- Telnet: cco.cisco.com.
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and connection rates up to 28.8 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact cco-help@cisco.com. For additional information, contact cco-team@cisco.com.

Note If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or tac@cisco.com. To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or cs-rep@cisco.com.

This document is to be used in conjunction with the *Cisco LocalDirector Installation and Configuration Guide*.

AccessPath, AtmDirector, Cache Director System, CD-PAC, Centri, Centri Bronze, Centri Gold, Centri Security Manager, Centri Silver, the Cisco Capital logo, Cisco IOS, the Cisco IOS logo, CiscoLink, the Cisco Powered Network logo, the Cisco Press logo, ClickStart, ControlStream, Fast Step, FragmentFree, IGX, JumpStart, Kernel Proxy, LAN²LAN Enterprise, LAN²LAN Remote Office, MICA, Natural Network Viewer, NetBeyond, Netsys Technologies, Packet, PIX, Point and Click Internetworking, Policy Builder, RouteStream, Secure Script, SMARTnet, StrataSphere, StrataSphere BILLder, StrataSphere Connection Manager, StrataSphere Modeler, StrataSphere Optimizer, Stratm, StreamView, SwitchProbe, *The Cell*, TokenSwitch, TrafficDirector, VirtualStream, VlanDirector, Workgroup Director, Workgroup Stack, and XCI are trademarks; The Network Works. No Excuses. is a service mark; and BPX, Catalyst, Cisco, Cisco Systems, the Cisco Systems logo, EtherChannel, FastHub, FastPacket, ForeSight, IPX, LightStream, OptiClass, Phase/IP, StrataCom, and StrataView Plus are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners.

Installing Circuit Boards in the Cisco LocalDirector

Copyright © 1997, Cisco Systems, Inc.

All rights reserved. Printed in USA.

9710R